FP-2K90INT-4A

RC2000 Antenna Interface Box

Installation Kit

V. 1.4 Contents Subject to Change 2/18/11

Research Concepts, Inc. 9501 Dice Lane Lenexa, Kansas 66215 USA Phone: 913/422-0210 • Fax: 913/422-0211 www.researchconcepts.com

Manual Revision History

Revision 1.1

6/28/01 Added Appendix for EASi 1 1/2 HP -2E version. Dual-Speed operation.

Revision 1.2

- # 4/05/02 Added new heater option/information, starting with S/Ns: 6015-6018.
- # 4/25/02 Updated Bill of Materials.

Revision 1.3

- # 3/03/09 Revised schematic for the EASi 4.5 Meter Antenna Installation Kit.
- *ѧ* 3/03/09 Updated Bill of Materials for the Antenna Interface Unit.

Revision 1.4

- 2/18/11 Revised document to describe the use of the Minarik RG60U motor drive instead of the KB Electronics KBPB motor drive. Added RG60U User's Manual.
- $\cancel{}$ 08/14/14 Fixed the windings on PG13 Figure 7

Table of Contents

1. Introduction	1
RC2K90INT-1 and RC2K90INT-2 Interface Boxes	1
RC2KINT Interface Box	1
Polarization Control	1
Dual-Speed Antenna Azimuth and Elevation Movement	2
1	
2. Theory of Operation	2
2.1 Controlling the Motors	2
Figure 1	3
2.2 Position Sensor Interface	4
Figure 2	4
2.3 Polarization Control	5
3. Circuit Description	5
MINARIK DC Motor Drive Module	5
Figure 3	5
2K90INT-2 Circuit Board	6
Figure 4.	8
Figure 5	9
- 3. Figure 6	10
0	
4.0 Heater Option	11
E Installation / Ostur	
5. Installation / Setup	11
5.1 Mechanical Installation	11
5.2 Electrical Installation	11
5.2.1 Connecting to the AC Mains	11
5.2.2 Connections to the RC2000	12
Figure 7	13
5.2.3 Antenna Motor and Limit Switch Connections	13
5.3 RC2000 CONFIGURATION	14
5.3.1 Required CONFIG Mode Settings	14
5.3.2 Optional CONFIG Mode Settings	14
5.4 Interface Box Adjustments	15
5.4.1 Speed Control	15
5.4.2 IR Compensation	15
5.4.3 Fusing	15
Appendices and Attachments	15
Bill of Materials	16
Minarik RG6011 User's Manual	18
Power PCB Relay	50
KBPB Operating Instructions	54
POWER/MATION	58
GEMCO Rotary Limit Switch	59
Eurostrips	60
Electric Heater	61
EASi 4.5 Meter Antenna Installation Kit	63
1 Introduction	63
2 Act rower.	03
5 Amenina Controller to Interface Box Interconnect Cable	03

4	Making the Connections	64
	Figure E1	66
	Figure E2	67
	Figure E3	68
5	RC2000 Software Configuration	69
6	Bill Of Materials	71
	Installation Kit	71
	Antenna Interface Unit	72
7	Installation Checklist	73
8	Tools and Materials Required For Installation	73
9	Attachments	73

1. Introduction

This document describes a family of products that allow an RC2000 antenna controller to interface with antennas powered by either 90 or 180 volt DC motors (RC2K90INT-1 and RC2K90INT-2) or other motor types (RC2KINT). The RC2000 antenna controller is designed to interface directly with antennas which employ 36-Volt DC motors (8 amps maximum) and single phase pulse type position sensors. When the RC2000 is used with antennas powered by other types of motors an interface box is required.

Three unique interface box configurations are available from Research Concepts. These configurations are designated RC2K90INT-1, RC2K90INT-2, and RC2KINT. All versions of the interface are housed in NEMA 4 type enclosures that are suitable for outdoor mounting.

RC2K90INT-1 and RC2K90INT-2 Interface Boxes

The RC2K90INT-1 and RC2K90INT-2 interface boxes are designed to interface with either 90 volt or 180 volt DC motors. The RC2K90INT-2 interface box employs a pair of DC motor drive modules and supports simultaneous movement about the antenna's azimuth and elevation axis. The RC2K90INT-1 interface box employs a single DC motor drive module and simultaneous azimuth and elevation movement is not supported.

The DC motor drive modules used in these interface boxes provide dynamic braking of the motors and are available in either 115 or 230 VAC input voltage versions. The following table gives the maximum motor horsepower as a function of AC input voltage and motor voltage.

Input Voltage	Motor Voltage	Maximum Motor Horsepower
120 Volts AC	90 Volts DC	1 horsepower
240 Volts AC	90 Volts DC	1 horsepower
220 Volts AC	180 Volts DC	2 horsepower

When ordering an RC2K90INT-1 or an RC2K90INT-2 interface box please specify the AC line voltage, the DC motor voltage and the motor horsepower, and whether two-speed operation, described later in this section, is required.

RC2KINT Interface Box

The RC2KINT interface box consists of the 2K90INT-2 circuit board mounted in a NEMA 4 type box. The circuit board provides uncommitted relay contact closures to activate motor drive control devices provided by the user.

Polarization Control

The RC2000 antenna controller is designed to directly interface with three wire servo type polarization control devices. An optional daughter board (designated RC2KPOL) can be installed on most RC2000 models which provides an interface to a 24 volt DC polarization control motor (400 ma) which uses a potentiometer for position sense feedback. The RC2KPOL daughterboard is compatible with many Seavey Engineering rotating feeds. All of the interface boxes described here provide contact closures which can be used to provide polarization control for antennas which use motors other than 24 volts DC. For these applications it is necessary to install the optional RC2KPOL daughter board in the RC2000 antenna controller. Please contact Research Concepts for more information.

Dual-Speed Antenna Azimuth and Elevation Movement

The RC2000 antenna controllers use a pulse width modulation scheme to obtain slow speed movement when interfaced to 36 volt DC motors. This pulse width modulation scheme is not compatible with the interface box. When the RC2000 A and C model antenna controllers are used with the interface boxes described here, antenna azimuth and elevation movement occurs at fixed speed(s) - the controller's pulse width modulated speed control system must be disabled (from the keypad). These speed(s) are set by the installer via potentiometers located in the RC2K90INT Interface Box. With Dual-Speed interface boxes, two-speed motion is implemented by using the RC2000A's (former) polarotor output to specify the speed. The polarotor output becomes the speed control bit when the *ROTATING FEED PRESENT?* CONFIG Mode item is set to 1. If polarization control is required with a dual speed interface box, the RC2KPOL option must be the polarization control entity. The RC2000 / 2K90INT system does support Polarotor-servo type polarization control schemes but only when operating with a single-speed interface box. A special version of the RC2000C code implements the dual-speed option.

2. Theory of Operation

The two issues which must be addressed to interface an RC2000 controller to a large antenna is the application of power to the antenna motors and sensing of the antenna's position. Polarization control may also be an issue. Applying power to the antenna will be addressed first.

2.1 Controlling the Motors

Figure 1 shows a schematic representation of a single axis (in this case azimuth) of the antenna control system. The output of the RC2000 on the AZ1 and AZ2 terminals will be +/- 36 volts. When AZIM CCW (east in the northern hemisphere) movement is specified, AZ1 will have the higher voltage, and when AZIM CW (west in the northern hemisphere) movement is specified, AZ2 will have the higher voltage. In a similar fashion, when down movement is specified, EL1 will be at the higher voltage, and when upward movement is specified, EL2 will be at the higher potential. When east movement is specified, current will flow out of the AZ1 terminal of the RC2000, through the dropping RESISTOR, R. The purpose of the dropping resistor is to match the output voltage of the RC2000 (nearly 40 volts) to the voltage rating of the relay coils. The current then continues through STEERING DIODE D1, through the east RELAY COIL, through the EAST LIMIT SWITCH, through the EAST RELAY COIL will activate the relay and close the EAST CONTACT CLOSURE. This will configure the POWER CONTACTOR to move the antenna in the east direction. When east current flows STEERING DIODE D2 keeps current from flowing through the west RELAY COIL.

When the antenna is within the east limit, the EAST LIMIT SWITCH remains closed. When the east limit is reached, the EAST LIMIT SWITCH will open. When this occurs, STEERING DIODE D3 will keep east current from flowing, but will allow west current to flow. West movement limiting is accomplished in a similar fashion. Note that limit switches are not required. The RC2000 series controllers maintain logical limits based on the position count. Limit switches are pretty cheap insurance, however.

The circuit shown in Figure 1 shows the relay contacts activating power contactors that control the motor drive power. The key part of the circuit outlined in Figure 1 is the use of the AZ1 and AZ2 outputs of the RC2000, the dropping resistor, the relays, steering diodes, and the limit switches to generate contact closures which can be used to control the antenna's azimuth motor.



3

Note that the scheme shown in Figure 1 does not support slow speed movement. RC2000 antenna controllers normally vary motor speed by rapidly switching the 36 volt antenna drive signals off and on - which gives an average voltage of less than 36 volts. If this pulse width modulated signal is applied to the circuit of Figure 1, the relays would chatter and produce erratic operation. When using the interface boxes described here with the RC2000, slow speed operation should be disabled on the controller by setting the azimuth and elevation slow speed codes to 254. The single speed of the interface box is adjusted by varying a pot on the drive module(s).

Slow speed movement via the interface box is supported however. The RC2000 software can use the controller's polarotor output to control a relay which provides a pair of contact closures (NO, COM, and NC) which specify fast or slow speed antenna movement. Note that polarotor control is not supported with the RC2000 controller in this mode but polarization control via the optional RC2KPOL daughterboard is still available.

2.2 Position Sensor Interface

The RC2000 series of antenna controllers require the use of single phase pulse type sensors to determine the position of the antenna. A pulse type sensor produces a rectangular shaped waveform as the antenna moves about the axis associated with the sensor. The RC2000 antenna controllers are not compatible with quadrature pulse sensors. 5.7 volts DC is available on the back of the RC2000 (at connector J1-11) to provide power for the pulse sensors.

The RC2000 controllers count the number of rising and falling edges of the waveform. The position count is decremented for east (or down) movement and incremented for west (or up) movement. Referring to Figure 2, the waveform's high level should be 4.5 to 5.7 volts, and the low level should be 0.0 to 0.5 volts. The waveform's minimum high or low pulse duration should be at least 10 milliseconds. This means that pulses less than 10 milliseconds long may not be detected by the antenna controller. The maximum number of counts from the antenna's east limit to its west limit should be less than 65000. Remember, each rising edge and each falling edge of the sensor's output waveform is a separate count.



Figure 2

4

Many large antennas use a sensor attached directly to each of the fundamental axis of the antenna. The sensor used may be a synchro, potentiometer, or a quadrature pulse encoder. A pulse type sensor attached to the fundamental axis of the antenna is not suitable for use with RC2000 antenna controllers. The reason for this requires a bit of explanation.

When a rising or falling edge is detected on the antenna controller's sensor input, the antenna controller must determine whether to increment or decrement the position count. Since single phase pulse sensors are used, the antenna controller must determine which way the antenna was last commanded to move, and decrement or increment the count accordingly. With a pulse sensor connected directly to the antenna's fundamental axis, when the antenna vibrates back and forth due to wind, the pulse sensor produces a steady stream of pulses. The antenna controller will increment or decrement the count depending on which way the antenna was last commanded to move. In reality the antenna is just vibrating in the wind and not really moving. The result of this is an error in the position count maintained by the antenna controller.

The antenna controllers are designed to work with 36 volt actuators. With these actuators the pulse sensor is connected directly to the motor. The motor typically drives either a worm or screw type gear, which will not transmit wind motion from the antenna back to the motor. Therefore, no false counts are recorded by the antenna controller. By placing a Hall-effect sensor on the shaft of the antenna motors drive, a similar decoupling of wind vibration is achieved. On certain models of the RC2000 it is possible to disable the accumulation of position pulses when the antenna is not commanded to move (or is in a coast interval immediately following the release of the motor drive lines).

2.3 Polarization Control

If the polarization is controlled with something other than a polarotor, then an interface for a polarization motor is necessary. Many popular rotating feeds use a 24 VDC motor with a potentiometer as the position feedback device. These feeds can be driven directly by the RC2000 with the RC2KPOL option (ordered separately). The RC2KPOL drive provides greater than 200mA @ 24 Volts for these feeds. In the event that a high voltage DC or AC motor is used to drive the polarization axis, a scheme similar to that described above for controlling the azimuth and elevation motors can be used with the RC2KPOL option

3. Circuit Description

The interface boxes described in the this document use a common printed circuit board to generate the contact closures (described in the previous section) required to control the azimuth, elevation, and (if needed) polarization axis of the antenna. That printed circuit board is designated 2K90INT-2.

The RC2KINT interface box consists of the 2K90INT board in a NEMA 4 enclosure. The user is responsible for using the contact closures generated by the circuit board to control the antenna.

The RC2K90INT-1 interface box uses a single MINARIK motor drive module. The motor drive module accepts AC line voltage and contact closures produced by the 2K90INT-2 circuit board and generates the drive voltage used to power the motors. The motor drive voltage produced by the MINARIK motor drive module is routed back onto the circuit board where a latching relay directs the current to either the azimuth or the elevation axis. Simultaneous azimuth and elevation movement is not possible with the RC2K90INT-1 interface box.

The RC2K90INT-2 interface box employs a pair of MINARIK motor drive modules. Line voltage is connected to both motor drive modules and each motor is directly connected to a motor module - motor drive voltage does not pass through the 2K90INT-2 circuit board. With the RC2K90INT-2, simultaneous azimuth and elevation movement is permitted.

MINARIK DC Motor Drive Module

The RC2K90INT-1 and RC2K90INT-2 interface boxes employ MINARIK DC motor drive modules manufactured by Minarik Drives. The MINARIK motor drive modules use SCRs to rectify the AC line

voltage and control the voltage DC delivered to the armature of the motor being controlled. The Minstik RG-60U is designed for use with either 115 or 230 volt AC line voltage. The input voltage is selectable via two switches on the drive. These motor drive modules also provide speed control, electronic current limiting, IR compensation, and dynamic braking. The motor horsepower is set via a pot on the drive. The Operating instructions for the motor drive module(s) are included with the operating manual for the RC2K90INT-1 and RC2K90INT-2 interface boxes.

The line voltage is applied to the L1 and L2 terminals. The direction and armature voltage (and motor speed) can be varied by terminals S0, S1, S2 and S3. The following diagram shows an example of how the relay contact closures and potentiometers on the 2K90INT circuit board can be used to adjust the direction and speed output of the MINARIK drives.





2K90INT-2 Circuit Board

Figure 3 is a schematic of the 2K90INT-2 circuit board. The circuit which includes relays K2 and K3 generates the contact closures required to control the azimuth axis as described in figure 1 above. The azimuth +/-36 volt output of the RC2000 is applied to the terminals labeled AZ1_CTL and AZ2_CTL. The east and west limit switches and their associated steering diodes are connected to the terminals labeled AZLIM1 and AZLIM2. If limit switches are not used a jumper can be connected between the AZLIM1 and AZLIM2 terminals. When east current flows relay K2 activates which in turn connects the terminal labeled S2_KBPB1 to the terminal labeled S1_KBPB1. In a similar fashion, when west current flows relay K3 is activated and the terminal labeled S2_KBPB1 is connected to the terminal labeled S1_KBPB1.

The elevation control circuit consisting of relays K5 and K6 operate in a manner identical to the azimuth circuit. The control signals are applied via the EL1_CTRL and EL2_CTRL terminals. The contact closures associated with these relays are available at terminals S1_KBPB2, S2_KBPB2, and S3_KBPB2.

The polarization control circuit is implemented with relays K7 and K8. The control inputs for this circuit are generated by the an RC2KPOL board installed in the RC2000 antenna controller and are applied to the circuit board via the P1_CTL and P2_CTL inputs. The contact closures associated with polarization control are available at connector J8. The user is responsible for using these contact closures to realize a polarization control scheme for the polarization motors used on his or her antenna.

The circuit associated with latching relay K4 is used by the RC2K90INT-1 interface box. With the RC2K90INT-1 interface box a single KBPB DC motor drive module is present and the latching relay is used to route the motor drive current to either the azimuth or elevation axis. The relay will not be included with the RC2K90INT-2 and RC2KINT model interface boxes. When an azimuth control input signal is applied to the AZ1_CTL and AZ2_CTL inputs the K4 relay coil labeled 'LATCH_AZ' on the schematic is energized and the inputs labeled A1_KBPB and A2_KBPB (connected to the A1 and A2 outputs of the KBPB) are connected to the azimuth motor via the AZMOT1 and AZMOT2 outputs. The diode bridge formed by diodes D6, D7, D8, and D9 insures that an azimuth control signal of either polarity will result in a unipolar voltage being applied to the 'LATCH_AZ' coil of the relay. When the azimuth control signal generated by the RC2000 is removed the latching relay stays in the 'azimuth' position.

In a similar fashion, when an elevation control input signal is applied to the EL1_CTL and EL2_CTL inputs the 'RESET_EL' coil of the K4 relay is energized and the relay contacts are configured to connect the A1_KBPB and A2_KBPB contacts to the elevation motors via the ELMOT1 and ELMOT2 outputs. The diode bridge formed by D12, D13, D14, and D15 allows an elevation drive current of either polarity to activate the 'RESET_EL' coil of the relay. When the elevation control input is removed the relay will stay in the 'elevation' position until an azimuth input is applied. It is necessary to use a latching relay to select the azimuth or elevation axis to support the dynamic braking capability of the motor drive module. If a non latching relay were used, when the control input is removed (for one of the two axis) the relay would switch while the motor is braking (and current is flowing). This would defeat the braking action and generate noise as the relay contacts open with a load applied.

The RC2000D antenna controller supports dual speed azimuth and elevation movement when used with the interface box. With the RC2000D software the controller's polarotor control output may be used to activate relay K1 on the 2K90INT-2 board. This relay provides a pair of speed control channels which can be used with either the KBPB DC motor drive module (in the RC2K90INT-1 or RC2K90INT-2 interface boxes) or a user supplied controller (with the RC2KINT interface box) to obtain dual speed azimuth and elevation movement. When used with other members of the RC2000 controller family only single speed azimuth and elevation movement is available.

The K1 relay is powered with 5.7 volts DC via the terminals labeled +5.7V and Return. 5.7 volts is available at the back panel of the RC2000 antenna controller. To activate the relay (and select high speed movement) 5 volts is applied to the terminal labeled Pulse. Resistor R1 is a dropping resistor on the base of transistor Q1 to limit the voltage at the base to approximately 0.7 volts. When Q1 turns on the relay is activated. The relay provides two speed control channels. Each channel consist of a pair of potentiometers. Only a single channel will be considered. For the KBPB1 speed control channel, the KBPB1_FST and KBPB1_SLO pots (designated P2 and P3, respectively) are connected to the P3_KBPB1 and P1_KBPB1 terminals. When fast speed is selected the voltage at the wiper of the KBPB1_FST terminal is presented to the P2_KBPB1 terminal. When slow speed is selected the voltage on the wiper of the KBPB1_SLO pot is connected to the P2_KBPB1 terminal. If contact closures are required rather than switched potentiometer wipers the potentiometers can be replaced with jumpers.

Diodes D1, D4, D5, D10, D11, D18, D19, D22, and D23 are used to suppress the back emf induced in the relay coils when the relays are de-energized. These are sometimes referred to as 'buck diodes'.

The connection of the 2K90INT-2 circuit board to the KBPB DC motor drive module(s) varies with the type of interface box (RC2K90INT-1 or RC2K90INT-2) as well as the type of controller (the RC2000D software supports dual speed azimuth and elevation movement, other models of the RC2000 controller only support single speed azimuth and elevation movement). The wiring schematics for the various configurations are given in figures 4, 5 and 6.



Figure 4



Figure 5



Figure 6

4.0 Heater Option

A heater option has been developed for the RC2K90INT series of interface boxes. The Minarik Drives RG60U Drive used in RCI 90VDC interface boxes has a low temperature rating of 10 C. This is inadequate for most environments. The heater option, designated RC2K90INT-HTR adds a maximum of 100W of heating to the box allowing a no-wind low temp of -50F for the std. 12 x 12x 6 inch interface box.

The Heater option uses a SPST thermostat that turns on at 32° F. Two 115VAC 54W heating pads are wired in series for 230VAC –rated boxed and parallel for 115VAC –rated boxes. The heating pads are attached to the underside of the baseplate with special high-temperature adhesive. the thermostat and heaters are protected with a single fuse in line with the Hot AC input.

5. Installation / Setup

This section describes the installation and setup of the interface box.

5.1 Mechanical Installation

The standard interface box is housed in a 12" by 12" by 6" (height x width x depth) NEMA 4 enclosure. NEMA 4 enclosures are suitable for outdoor use. The interface box is designed to be mounted vertically on the antenna kingpost. The mounting holes are suitable for 1/4 inch screws. The hole pattern is 10" (wide) by 12 3/4" high. The hinge is located on the left side of the box. Six 7/8" holes are punched in the bottom of the box. These holes are designed for 1/2 inch electrical conduit fittings.

Higher power (³/₄ HP to 1 ¹/₂ HP at 115VAC, or 1 ¹/₂ HP to 3 HP at 230VAC) versions of the interface box are housed in a 20" by 20" by 8" NEMA4 enclosure. The larger box has a bolt pattern 14" wide by 21 ¹/₄" high.

5.2 Electrical Installation

This sections covers the electrical connections required to connect the interface box to the AC mains, RC2000 antenna controller, and the antenna motors, limit switches, and sensors. Please refer to the wiring diagrams shown in figures 4 and 5. The AC power to the interface box should be disconnected whenever the interface box is opened - lethal voltages are present inside the box.

5.2.1 Connecting to the AC Mains

It is the user's responsibility to provide AC power at the antenna. An AC disconnect which removes all AC power to the interface box **must** be provided **at the antenna**. Each ungrounded AC line supply conductor must be fused. The interface box is available in two versions, one for use with 120 VAC and another for use with 240 VAC. The AC input voltage required is listed on the inside of the box lid. The connection to the AC mains is made directly to the L1 and L2 inputs on the KBPB motor drive module(s) in the smaller configurations (12x12x6 Housing) and to a 16-terminal block in the larger (20x20x8 Housing) configuration. A ground connection must be made to the ground lug located in the upper left hand corner of the box. The capacity of the AC service should be sufficient to carry the load required by the motors. For the RC2K90INT-2 remember that both motors will be running simultaneously.

5.2.2 Connections to the RC2000

A single cable is often used to connect the RC2000 to the interface box. The only connections required for operation of the interface box are those to the RC2000 azimuth and elevation drive outputs. Each axis requires a pair of conductors. Since the RC2000 motor drive outputs are not actually carrying motor drive current light gauge conductors (16-20 AWG) can be used, shielded cables are not required.

In most cases the cable used to connect the RC2000 to the interface box will also include the conductors required to interface the RC2000 to the azimuth and elevation position sensors. Each sensor requires 3 conductors in a shielded cable with a drain wire. The conductors in the sensor cable don't carry much current, 22 to 18 gauge conductors work fine. In some cases it will be necessary to splice sensor cables in the interface box. Figure 7 is an example of a sensor cable splice.

When making sensor connections please note the following ...

- Always use shielded cables.
- The shield drain wire should only be connected at the RC2000.
- If the cable is spliced, be sure to splice the drain wire.
- Don't allow the shield or drain wire to come in contact with ground anywhere. If the cable insulation is cut at a splice put a piece of heat shrink over the frayed shield to keep it from coming in contact with ground.
- Don't connect the drain wire or shield at the sensor.

Failure to follow these guidelines can result in unreliable operation of the pulse counters and antenna controller positioning errors

Shielded Sensor Cable Splice Inside the Interface Box



Notes:

- 1. Make sure that the drain wires are spliced.
- Do not allow the drain wire or foil to come into contact with ground.
- Remove the foil shield and drain wire on the sensor end of the cable. Cover the break in the cable so that the shield cannot come into contact with the ground.
- Use a cable tie for strain relief and to hold the conductors together to minimize the EMI loop area.

Figure 7

5.2.3 Antenna Motor and Limit Switch Connections

The motor conductors should be sized appropriately for the motor load. Three conductor cable should be used so that the ground terminal of the motor can be connected to the ground lug in interface box. The

13

limit switch conductors carry very little current, a pair of 20 to 18 gauge conductors are sufficient for the limit switch connections.

5.3 RC2000 CONFIGURATION

Via **CONFIG** mode, the user can optimize the operation of the controller for use with the interface box. Certain **CONFIG** mode items must configured in a certain manner to insure proper operation of the interface box. Other **CONFIG** mode items can optionally be configured so as to optimize the operation of the controller for use with the interface box.

5.3.1 Required CONFIG Mode Settings

A number of RC2000 **CONFIG** mode items must be configured properly for reliable operation of the RC2000 with the interface box. Here is a list of those items ...

CONFIG Mode Item	Required Value for Operation with Interface Box	Comments
Azim Slow Speed	254	A slow speed value of 254 disables the RC2000's pulse width modulation based slow speed system. Failure to properly configure this CONFIG mode item can result in damage to the interface box.
Elev Slow Speed	254	A slow speed value of 254 disables the RC2000's pulse width modulation based slow speed system. Failure to properly configure this CONFIG mode item can result in damage to the interface box.
Simultaneous Az/El Enable	0 - DISABLE	With the RC2K90INT-1, simultaneous azimuth and elevation movement is not allowed. With the RC2K90INT- 2, the user will generally want to enable simultaneous azimuth and elevation movement
Az/El Slow Deadband	See the comments.	The value of the Az/El Slow Deadband item should be set to approximately the same value as the Az/El Fast Deadband for interface boxes which only support single speed azimuth and elevation movement. Please see the discussion of these CONFIG mode items in the next section.

5.3.2 Optional CONFIG Mode Settings

The Az/El Drive Options **CONFIG** mode item controls access to the antenna movement parameters. The antenna movement parameters control the movement of the antenna (i.e. the number of attempts which will be made to hit a target position, the maximum allowable error, the coast distances, etc.). The default movement parameters of the RC2000 are optimized for antenna's powered by 36 volt linear actuators. In almost all cases the default values for these **CONFIG** mode items are not appropriate for antennas powered by other types of motors. Most antennas used with the interface box have drive systems with more inertia and more counts per degree of movement than antennas powered by 36 volt linear actuators. Please refer to the discussion of these **CONFIG** mode items in the RC2000 manual. Failure to properly configure these **CONFIG** mode items can result in inaccurate antenna positioning and/or excessive wear on the motors and actuators.

Two of the **CONFIG** mode items have special features which are often useful in interface box applications. The last two digits of the Az/El Fast Deadband parameter can be configured so as to disable

antenna runaway errors. The last two digits of the Az/El Slow Deadband parameter can be configured so as to address the problem of gaps in the program track table which contains a map of an inclined orbit satellite's apparent motion. For a discussion of these features of these two **CONFIG** mode items please refer to the RC2000C manual, Section 7.3 - Operational Troubleshooting Tips.

Many interface box applications are used for inclined orbit satellite uplinks. For transmit applications it is generally advisable to disable the controller's Search Enable **CONFIG** mode item. When the search is enabled, if the antenna is steptracking and the controller's AGC input indicates that the satellite signal has been lost the controller will initiate a search. During a search the controller sweeps the antenna over a parallelogram shaped region where it has calculated that the satellite is likely to be found. This is generally not desirable for transmit applications.

5.4 Interface Box Adjustments

Several user adjustments are available on the KBPB motor drive module and the 2K90INT-2 board located in the interface box. The most common adjustment made is to vary the speed of the motors. On interface boxes made for single-speed antenna movement, the speed is adjusted using R14 on the KBPB motor drive. This pot is labeled 'AUX' or R14. Please refer to the KBPB manual for the location of this pot. **The AC power to the interface box should be disconnected whenever the interface box is opened - lethal voltages are present inside the box.**

5.4.1 Speed Control

For interface boxes configured for dual speed azimuth and elevation movement, the slow speed adjustment pots are located on the 2K90INT-2 circuit board. For the RC2K90INT-1 interface box adjust the KBPB1_SLO pot to vary the slow speed for both the azimuth and elevation axis. Adjust the KBPB1_FST pot to set the fast speed for both axis. For the RC2K90INT-2 interface box the KBPB1_SLO and KBPB1_FST pots are used to adjust the speed of the azimuth axis. The KBPB2_SLO and KBPB2_FST pots are used to adjust the speed of the elevation axis. The maximum and minimum fast and slow speeds for each KBPB are determined by the MAX and MIN trimpots located on each KBPB. Normally the user should not need to adjust these pots - they are set for maximum speed-range when the interface box is assembled.

5.4.2 IR Compensation

Other trimpot adjustments present on the Minarik drive is the IR compensation. IR compensation is used to increase the voltage to the motor when the motor is loaded so as to maintain a constant speed. No adjustment of this trimpot should be necessary. If adjustments are necessary please refer to the Minarik RG60U operating instructions included with this manual.

5.4.3 Fusing

The Minarik motor drive module must be protected by a Line Fuse. An AC line fuse of 20 amps is appropriate for 90 VDC motors of up to 1 HP and 180 VDC motors of up to 2 horsepower. The fuse is a normal blow, ceramic type (Buss type ABC, Littlefuse type 314, or equivalent). For more information on fusing please refer to the Minarik RG60U operators manual.

Appendices and Attachments

This section includes the following attachments ...

• Minarik RG60U Manual (for model RC2K90INT-1 and RC2K90INT-2 interface boxes)

- A data sheet on the Omron type G2R relay.
- A data sheet on the Potter and Brumfield KUL-11D15D-24 type relay (RC2K90INT-2 only)
- The silk-screen mask of the 2K90INT-2 circuit board
- The bill of materials
- Any appendices related to custom versions of the interface box.

Bill of Materials

Ouan	Model/Description	Manufacturer	Comments (Ref Designators)
1	G2R-2-S-5VDC Relay	Omron	DPDT Relay, 5VDC Coil, (K1)
1	P2R-08P Socket	Omron	Socket for DPDT Omron Relay
4	G2R-1-S-24VDC Relay	Omron	SPDT Relay, 24VDC Coil, (K2, K3, K5, K6)
2	G2R-1-S-12VDC Relay	Omron	SPDT Relay, 12 VDC Coil, (K7, K8)
6	P2R-05P Socket	Omron	Socket for SPDT Omron Relay
1	KUL11D15D24	Potter and Brumfield	DPDT Latching Relay, Dual 24VDC Coil (K4)
1	27E046	Potter and Brumfield	Socket for Latching Relay
1	20C247	Potter and Brumfield	Anchor Clip for Latching Relay
23	1N4002	Motorola	Diode (D1-D23)
4	3329H-1-502 Pot	Bourns	5K Ohm, 1 Turn Potentiometer (P1-P4)
1	2N4400 Transistor	Motorola	NPN Transistor (Q1)
1	200 Ohm, 1/8 Watt		Resistor (R1)
2	200 Ohm, 2 Watt		Resistor (R2,R4)
2	680 Ohm, 1/2 Watt		Resistor (R3, R5)
1	240 Ohm, 1 Watt		Resistor (R6)
5	150626 Connector	Weidmuller	2 Position Screw Terminal Connector
9	150646 Connector	Weidmuller	3 Position Screw Terminal Connector
2	Z320LA15A	CKE	320 Volt Metal Oxide Varistor (MOV1,
			MOV2)
2	7105U15SYZ3QE	C & K	SPDT (MOM-OFF-MOM) Switch (SW1, SW2)
1 or 2	KBPB-125 or KBPB-225	KB Electronics,	DC Motor Drive Module, the KBPB-125 is
		Inc.	used with 120 VAC Versions of the Interface
			Box, the KBPB-225 is used with 220/240 VAC
	< 22 - 2/011 C		Versions of the Interface Box [2] [3]
2	6-32 x 3/8" Screw		Phillips Head Screw for Latching Relay Socket
2	#6 Lockwasher		Lockwasher for Latching Relay Screw
2	6-32 Small Outline Nut		Nut for Latching Relay Screw
4	??" Standoff		Circuit Board is Mounted on These Standoffs
4	?? Nut w/ Nylon Insert		For Use with Standoff
4	?? Screw		Connects Standoff to the Mounting Panel
2 or 4	?? Screw		KBPB Mounting Screw [1]
2 or 4	?? Washer		Used with KBPB Mounting Screw [1]
2 or 4	?? Lock Washer		Used with KBPB Mounting Screw [1]
2 or 4	?? Nut		Used with KBPB Mounting Screw [1]
1	1414 PHL6LP	Hammond Mfg.	12" x 12" x 6" NEMA 4 Enclosure with
			Panel[4]

Quan	Model/Description	Manufacturer	Comments (Ref Designators)
1	1418 N4D8	Hammond Mfg.	20"x20"x8" NEMA4 Encl. w/Panel [4]
4	Insulated Ring Terminal		Crimp Type, #10 Stud, 10-12 AWG Wire Size - Used for Motor and KBPB Chassis Ground Connection

Notes

- 1 2 are used for the RC2K90INT-1, 4 are used for the RC2K90INT-2
- 2 Only one motor drive module is used for the RC2K90INT-1, two motor drives are used for the RC2K90INT-2.
- 3 When a KBPB-225 motor drive module is used with a 90 volt DC motor the KBPB should be modified as described in Section 4.4.4. It is not necessary to perform this modification on new Interface Boxes if 220/240 VAC line voltage and 90 volt DC motors are specified when the interface box is ordered (the modification is performed at the factory).
- 4 12x12x6 box used up to 3/4HP 115VAC or up to 1 ½ HP 230VAC systems. The 20x20x8 box is used up to 1 1/2HP 115VAC or up to 3 HP 230VAC systems.







=	
Contents	
Regenerative Drives	÷
Specifications	÷
Dimensions	÷
Installation	:
Mounting	÷
Wiring	÷
Shielding guidelines	÷
Heat sinking	÷
Line fusing	:
Speed adjust potentiometer	÷
Connections	÷
Power, fuse and motor connections	:
Voltage follower (isolated signal)	÷
Line voltage switches	÷
Armature voltage switch	÷
Feedback selector switch	÷
Voltage or Current Follower (non-isolated signal, -PCM models)	÷
Operation	:
Before applying power:	÷
Startup and shutdown	÷
To start the drive:	÷
Starting and Stopping Methods	÷
Automatic restart upon power restoration	÷
Decelerate to a stop	÷
Coast to a stop	÷
Regenerative brake	÷
Invert Inhibit and Invert Enable	

Toubleshooting Before applying power Replacement Parts	Application Notes	Contraction MINIMUM SPEED (MIN SPD) MAXIMUM SPEED (MAX SPD) FORWARD TORQUE (FWD TQ) FORWARD TORQUE (FWD TQ) REVERSE TORQUE (REV TQ) IR COMPENSATION (IR COMP) FORWARD ACCELERATION (FWD ACC) REVERSE ACCELERATION (REV ACC) DEADBAND (DB) TACH GENERATOR (TACH) MAX (RG60U-PCM isolation card) OFFSET (RG60U-PCM isolation card) Contraction card)
	-REV 4444	4 4 08 37 66 64 4 0 8 3 2 8 3 3 3 6

20

R	
Illust	rations
Figure 1. F	Four Quadrant Operation
Figure 2. F	RG60U-PCM/RG61U-PCM Dimensions
Figure 4. \$	Speed Adjust Potentiometer
Figure 5. \$	Screw Terminal Block
Figure 6. (Figure 7	Cage-Clamp Terminal Block
Figure 8.	Speed Adjust Potentiometer Connections
Figure 9. V	Voltage Follower Connection
Figure 10.	Line Voltage Switches (bottom board)17
Figure 11.	Armature Voltage and Feedback
Figure 12.	RG-60U-PCM connections and jumper settings
Figure 13.	RUN/STOP Switch
Figure 14.	INHIBIT / ENABLE Terminal TB503
Figure 15	INUERT Settinge 28
Figure 16.	ENABLE Settings
Figure 17.	RG60U Calibration Trimpot Locations
Figure 18.	Deadband Settings
Figure 19.	Typical FWD TQ, REV TQ, and
Finine 20	IR COMP Trimpot Settings
Figure 21.	RG60U Connections to DLC600
Figure 22.	Forward-Reverse Switch
Figure 23.	Forward-Stop-Reverse Switch
Figure 24.	Independent Adjustable Speeds (Forward Direction) 45
Figure 25.	Independent Forward and Reverse Speeds
Figure 2b.	





Specificatic	Armature Current Range (ADC)	Armature Horsepower	Voltage Range (VDC)
	л С*	*GIL - 71L	0 - 00
	5.0**	1/4 - 1**	0 - 180
RG61U, RG61U-PCM	<u>1</u> ភ	1/20 - 1/8	0 - 90
	1.5	1/10 - 1/4	0 - 180
* Max. Armature Current = 10 Al			
 Max. Horsepower = 1 hp when ** Max. Armature Current = 10 A Max. Horsepower = 2 hp whe 	DC and - mounted to heat sink k .DC and n mounted to heat sink	dt part number 223-01 kit part number 223-0	159.
Max. Horsspower = 1 hp when ** Max. Armature Current = 10 A Max. Horsepower = 2 hp whe AC Line Voltage	DC and i mounted to heat sink k DC and n mounted to heat sink 115 VAC / 23	dt part number 223-01 ktt part number 223-0 30 VAC, ±10%, 50/6i	59. 159.) Hz, single phase
Max. Horsepower = 1 hp when ** Max. Armature Current = 10 A Max. Horsepower = 2 hp whe AC Line Voltage Form Factor	DC and i mounted to heat sink k DC and n mounted to heat sink 115 VAC / 23	dt part number 223-01 ktt part number 223-0 30 VAC, ±10%, 50/6	59. 159.) Hz, single phase .37 at base speed
Max. Horsepower = 1 hp when ** Max. Armature Current = 10 A Max. Horsepower = 2 hp whe Ac Line Vottage Form Factor Acceleration Time Range	DC and i mounted to heat sink k DC and n mounted to heat sink 115 VAC / 23	dt part number 223-01 ktt part number 223-0 30 VAC, ±10%, 50/60	59. 159.) Hz, single phase .37 at base speed 0.5 – 6 seconds
Max. Horsepower = 1 hp when *** Max. Armature Current = 10 A Max. Horsepower = 2 hp whe Ac Line Voltage Form Factor Acceleration Time Range Deceleration Time Range	r mounted to heat sink k LDC and n mounted to heat sink 115 VAC / 23	dt part number 223-0/ ktt part number 223-0 30 VAC, ±10%, 50/6/ 1	59. 159. 1 Hz, single phase 1 Hz, single phase 1.37 at base speed 0.5 – 6 seconds 0.5 – 6 seconds
Max. Horsepower = 1 hp when Max. Amature Current = 10 A Max. Horsepower = 2 hp whe AC Line Voltage Form Factor Acceleration Time Range Deceleration Time Range Analog Input Voltage Range (without -PCM option, sig	i DC and I DC and IDC and I DC and I I DC heat sink I I D VAC / 23 I D VAC / 23	dt part number 223-07 ktt part number 223-0 30 VAC, ±10%, 50/61	59. 159. 159. 177 at base speed 0.5 – 6 seconds 0.5 – 6 seconds 0.5 – 6 veconds
 Max. Horsepower = 1 hp when Max. Amature Current = 10 A Max. Horsepower = 2 hp whe AC Line Voltage Form Factor Acceleration Time Range Deceleration Time Range Analog Input Voltage Range Analog Input Voltage Range (without -PCM option, sig (mput Impedance (S0 to S2)) 	i DC and LDC and LDC and in mounted to heat sink 115 VAC / 23 gnal must be isolate	dt part number 223-01 ktt part number 223-0 30 VAC, ±10%, 50/6 30 VAC, ±10%, 50/6 4; S0 to S2)	59. 159. 159. 177, single phase 0.5 – 6 seconds 0.5 – 6 seconds
Max. Horsepower = 1 hp when Max. Amature Current = 10 A Max. Horsepower = 2 hp whe AC Line Voltage Form Factor Acceleration Time Range Deceleration Time Range Deceleration Time Range (without -PCM option, sig (without -PCM option, sig Input Impedance (S0 to S2) Load Regulation	DC and I mounted to heat sink k UDC and n mounted to heat sink 115 VAC / 23 gnal must be isolate	dt part number 223-01 ktt part number 223-0 30 VAC, ±10%, 50/6 30 VAC, ±10%, 1	59. 159. 1 Hz, single phase 0.5 - 6 seconds 0.5 - 6 seconds
Max. Horsepower = 1 hp when Max. Amature Current = 10 A Max. Horsepower = 2 hp whe AC Line Voltage Form Factor Acceleration Time Range Deceleration Time Range Analog Input Voltage Range (without -PCM option, sig Input Impedance (S0 to S2) Load Regulation with Armature Feedback with Tachogenerator Fee	DC and I mounted to heat sink k IDC and 115 VAC / 23 gnal must be isolater gnal must be isolater	dt part number 223-07 ktt part number 223-0 30 VAC, ±10%, 50/6 30 VAC, ±10%, 50/6	59. 159. 1 Hz, single phase 37 at base speed 0.5 - 6 seconds 0.5 - 6 seconds 0.5 - 6 seconds 30 kohms 30 kohms 1% base speed
Max. Horsepower = 1 hp when Max. Amature Current = 10 A Max. Horsepower = 2 hp whe AC Line Voltage Form Factor Acceleration Time Range Deceleration Time Range Analog Input Voltage Range (without -PCM option, sig Input Impedance (S0 to S2) Load Regulation with Armature Feedback with Tachogenerator Fee Vibration	DC and I mounted to heat sink k (DC and 115 VAC / 23 115 VAC / 24 115 VAC / 24 1	4t part number 223-07 ktt part number 223-0 30 VAC, ±10%, 50/61 30 VAC, ±10%, 50/61 4; S0 to S2) 0.50	59. 159. 159. 37 at base speed 0.5 – 6 seconds 0.5 –
Max. Horsepower = 1 hp when Max. Amature Current = 10 A Max. Horsepower = 2 hp whe AC Line Voltage Form Factor Acceleration Time Range Deceleration Time Range Control Input Voltage Range (without -PCM option, signing (without -PCM option, signing) Input Impedance (S0 to S2) Load Regulation with Armature Feedback with Tachogenerator Fee Vibration	DC and I mounted to heat sink k In mounted to heat sink 115 VAC / 23 gnal must be isolater dback	dt part number 223-07 ktt part number 223-0 30 VAC, ±10%, 50/6 	59. 142, single phase 37 at base speed 0.5 - 6 seconds 0.5 - 6 seconds 14 base speed 0.1% base speed 0.1% base speed 0.1% base speed 0.1% base speed
Max. Horsepower = 1 hp when Max. Amature Current = 10 A Max. Horsepower = 2 hp whe Form Factor Acceleration Time Range Deceleration Time Range (without -PCM option, sig (without -PCM option, sig Input limpedance (S0 to S2) Load Regulation with Armature Feedback with Tachogenerator Fee Vibration	DC and I mounted to heat sink k IDC and 115 VAC / 23 gnal must be isolater gnal must be isolater	d; S0 to S2) d; S0 to S2) 0.50	59. 159. 159. 37 at base speed 0.5 − 6 seconds 0.5 − 6 seconds 10.5 − 6 seconds 0.10 +/- 10 VDC 30 kohms 1% base speed 0.1% base speed 1.% bas







 Use 18 AWG wire for speed adjust potentiometer wiring. Use 14 AWG wire for AC line (L1, L2) and motor (A1, A2) wiring. 	Wiring Do not install, rewire, or remove this control with input power applied. Failure to heed this warning may result in fire, explosion, or serious injury. Circuit potentials are at 115 or 230 VAC above ground. To prevent the risk of injury or fatality, avoid direct contact with the printed circuit board or with circuit elements. Do not disconnect any of the motor leads from the drive unless power is removed or the drive is running may destroy the drive.	Installation 5
--	---	----------------



Installation

~

Heat sinking

between the drive chassis and the heat sink surface for optimum compound (such as Dow Coming® 340 Heat Sink compound) kit part number 223-0159. Use a thermally conductive heat sink continuous armature current is above 5 ADC. Use Minarik heat sink The RG60U drive requires an additional heat sink when the heat transfer.

Line fusing

25

acting fuses rated for 250 VAC or higher. Fuse L1 only when the is 230 VAC. line voltage is 115 VAC. Fuse both L1 and L2 when the line voltage Minarik drives should be used with fuses for protection. Use fast

Table 1 on page 8 lists the recommended line fuse sizes

ne Fuse Size:	zes
. DC Armature urrent (amps)	 AC Line Size (a)
0.5	3
0.8	ω
1.5 .5	σ
1.75	51
2.5	8
3.5	8
5.0	
òċ	ב תר
	. DC Armature



26









	Connect the speed adjust potentiometer as shown in Figure 8(b), page 15 for unidirectional operation in the forward direction. Connect the speed adjust potentiometer as shown in Figure 8(c), page 15 for unidirectional operation in the reverse direction. Refer to the Application Notes section for additional speed adjust potentiometer connections.	Speed adjust potentiometer connections The motor can operate in one direction (unidirectional) or two directions (bidirectional) depending on how the speed adjust potentiometer is connected to the drive. Connect the speed adjust potentiometer as shown in Figure 8(a), page 15 for bidirectional operation. The motor does not operate when the wiper is in the center position. Turning the wiper clockwise (CW) from the center position causes the motor to rotate in one direction, while turning the wiper counterclockwise (CCW) causes rotation in the opposite direction.	14 Installation
(b) Unidirectional Operation, (c) Unidirectional Operatio Forward Direction Reverse Direction Figure 8. Speed Adjust Potentiometer Connections	FWD WCOHM SPEED POT TBOD S S S S S S S S S S S S S	REV SPEED POT FWD FWD FWD FWD FWD FWD FWD FWD FWD FWD	Installation

29

ਹੋ








Minarik RG60U User's Manual

19

a voltage or current signal, connect the signal leads to the +IN and isolated) voltage or current signal. To configure the drive to follow PCM series drives can be configured to follow a grounded (non--IN terminals on TB501, observing proper polarity. Ensure that the

polarity, connect the DIR terminal to the +5V terminal on TB501 of a polarity reversal switch. Close the switch to reverse the output switch connections. to its original polarity. See Figure 12, page 20 for polarity reversa the PCM board. A single-pole, single-throw switch can be used as voltage polarity. Open the switch to return the output voltage back To reverse the output voltage polarity without changing the input





for AC IF
the motor or drive does not perform as described, disconnect the 2 line voltage immediately. Refer to the Troubleshooting section - further assistance.







	 Invert Inhibit and Invert Enable INVERT modes reverse the function of the INHIBIT and ENABLE terminals. Each drive is assembled with the INVERT INHIBIT and INVERT ENABLE jumper settings open (jumpers on location 1 and 4 of JP502). See Figure 14, page 27 for JP502 location. To activate the INVERT INHIBIT mode, jumper locations 1 and 2 of JP502 (see Figure 15, page 28). In INVERT INHIBIT mode, the motor will regeneratively brake when inhibit terminals are open. To activate the INVERT ENABLE mode, jumper locations 3 and 4, (see Figure 16, page 29). In INVERT ENABLE mode, the motor will coast to a stop when the enable terminals are open. To accelerate the motor to set speed, close the enable terminals. 	26 Operation
Figure 14. INHIBIT / ENABLE Terminal TB503 and JP502 Locations	INCERT INVERT ENABLE Jumper Settings (uP502)	Operation 27

I











Calibration ယ္ယ

FORWARD TORQUE (FWD TQ)

current rating, continuous operation beyond this rating may damage the motor. If you intend to operate beyond this rating Although FWD TQ can be set to 120% of motor nameplate contact your Minarik representative for assistance.

factory set at 120% of maximum rated drive current use the following procedure to recalibrate FWD TQ: See Figure 19 (page 39) for typical FWD TQ calibration settings or accelerating and driving the motor in the forward direction. The FWD TQ setting determines the maximum current limit for It is

- With the power disconnected from the drive, connect a DC

- Carefully lock the motor armature. Be sure that the motor is
- Slowly adjust the FWD TQ trimpot CW slowly until the armature
- current is 120% of motor rated armature current
- Set the speed adjust potentiometer to minimum.
- Remove the ammeter in series with the motor armature if it is
- no longer needed and re-apply power to the drive



IR COMPENSATION (IR C The IR COMP trimpot setting de motor speed is held constant as factory set for optimum motor re See Figure 19 (page 39) for typ use the following procedure to r 1. Set the IR COMP trimpot to 2. Rotate the speed adjust pote mid-speed without load (for e RPM motor). A hand held ta	OMP) termines the degree to which the motor load changes. It is gulation. cal IR COMP calibration settings acalibrate the IR COMP setting: ninimum (full CCW). ninimum (full CCW).
motor speed.	chometer may be used to measur
The motor should slow down	chometer may be used to measure
4. While keeping the load on th	chometer may be used to measur ts full load armature current rating
trimpot until the motor runs a	chometer may be used to measur ts full load armature current rating e motor, rotate the IR COMP
the motor oscillates (overcor	chometer may be used to measure the full load armature current rating armature the IR COMP the speed measured in step 2.
may be set too high (CW).	chometer may be used to measu ts full load armature current rating e motor, rotate the IR COMP t the speed measured in step 2. pensation), the IR COMP trimpot um the IR COMP trimpot CCW to
may be set too high (CW). 1 stabilize the motor.	chometer may be used to measu ts full load armature current rating e motor, rotate the IR COMP t the speed measured in step 2. tpensation), the IR COMP trimpot um the IR COMP trimpot CCW to

39

www.researchconcepts.com





မိ	Calibration
ΤA	CH GENERATOR (TACH)
	Calibrate the TACH setting only when a tachogenerator is used. The TACH setting, like the IR COMP setting, determines the degree to which motor speed is held constant as the motor load changes.
	To calibrate the TACH trimpot:
	1. Connect the tachogenerator to T1 and T2. The polarity is
	positive (+) for T1 and negative (-) for T2 with the motor running in forward direction.
	2. Set SW503 to ARM for armature feedback.
	3. Set the speed adjust potentiometer full CW. Measure the
	armature voltage across A1 and A2 using a voltmeter.
	 Set SW503 to TACH for tachogenerator feedback.
	6. Set the IR COMP trimpot to full CCW.
	7. Set the TACH trimpot to full CW.
	8. Apply line power.
	 Set the speed adjust potentiometer to full CW. Adjust the TACH trimpot until the armature voltage is the same
	value as the voltage measured in step 3.
	Check that the tachogenerator is properly calibrated. The motor should run at the same speed when SW503 is set to either
	armature or tachogenerator feedback.

Figure 19. Typical FWD TQ, REV TQ, and IR COMP Trimpot Setting	Image: Rev Tq Image: Rev Tq<	
t Settings	ion 39 2 HP 9.2 ADC 9.2 ADC 9.2 ADC 1 HP 180 VDC 5 ADC 180 VDC 3.44 HP 180 VDC 3.8 ADC 2.5 ADC	

Г













44







Problem	Possible Causes	Suggested Solutions
Line fuse blows.	1. Line fuse is the wrong size.	1. Check that the line fuse is correct for the motor size.
	2. Motor cable or armature is shorted to ground.	 Check motor cable and armature for shorts.
	3. Nuisance tripping caused by a combination of ambient conditions and high-current	3. Add a blower to cool the drive components; decrease FWD TQ and REV TQ
	spikes (i.e. reversing).	settings, or resize motor and drive for actual load demand, or check for mechanical components or "jams".

50 Troubleshootin	9	
Problem	Possible Causes	Suggested Solutions
Line fuse does not blow, but the motor does not run.	 Speed adjust potentiometer or speed reference voltage is set to zero speed. 	 Increase the speed adjust potentiometer setting or speed reference voltage.
	2. Speed adjust potentiometer or speed reference voltage is not connected to drive input properly; connections are open.	 Check connections to input. Verify that connections are not open.
	 INHIBIT terminals are shorted. 	3. Remove the short from the INHIBIT terminals.
	4. S2 is shorted to S0.	4. Remove short.
	5. Drive is in current limit.	5. Verify that motor is not jammed. Increase FWD TQ or REV TQ setting if they are set too low.
	6. Drive is not receiving AC line voltage.	6. Apply AC line voltage to L1 and L2.
	7. Motor is not connected.	7. Connect motor to A1 and A2.

Problem	Possible Causes	Suggested Solutions
Motor runs too fast.	MAX SPD not calibrated.	Calibrate MAX SPD.
Motor will not reach the desired speed.	1. MAX SPD setting is too low.	1. Increase MAX SPD setting.
	2. IR COMP setting is too low.	2. Increase IR COMP setting.
	3. Motor is overloaded.	3. Check motor load. Resize the motor if necessary.
	4. Drive is in current limit.	4. Verify torque settings.
Motor pulsates or surges under load.	1. IR COMP is set too high.	1. Adjust the IR COMP setting slightly CCW until the motor speed stabilizes.
	2. Motor bouncing in and out of current limit.	 Make sure motor is not undersized for load; adjust FWD TQ and REV TQ trimpot CW.

Fuse Kits	RG60U, RG61	Model No.		Replacen its distribu	Replac	52 Tro	
	1U SCR501–508 T501	. Symbol	Table 2.	nent parts are av utors for this driv	cement Parts	oubleshooting	
3–8A Fuse Kit 5–20A Fuse Kit	800 V, 25 A SCR DST-336 Transformer 10K Ohm Potentiometer Kit 2-Pin Jumper	Description	Replacement Parts	ailable form Minarik (e series.	UN.		
050-0069 050-0073	072-0067 230-0104 202-0104 164-0292	Minarik P/N		Corporation and			

Unconditional Warranty

returned to Minarik Corporation, 2011 USA. the Corporation will repair or replace, at its sole discretion, such products that are whichever comes first, from date of manufacture thereof. Within this warranty period, free from defects in workmanship and material for twelve (12) months or 3,000 hours A. Warranty Minank Corporation (referred to as "the Corporation") warrants that its products will be 901 East Thompson Avenue, Glendale, CA 91201-

This warranty applies only to standard catalog products, and does not apply to specials. Any returns for special controls will be evaluated on a case-by-case basis. The Corporation is not responsible for removal, installation, or any other incidental expenses incurred in shipping the product to and from the repair point.

B. Disclaimer

The provisions of Paragraph A are the Corporation's sole obligation and exclude all other warranties of merchantability for use, express or implied. The Corporation further disclaims any responsibility whatsoever to the customer or to any other person for injury to the person or damage or loss of property of value caused by any product that has been subject to misuse, negligence, or accident, or misapplied or modified by unauthorized persons or improperly installed.

48

C. Limitations of Liability In the event of any claim for breach of any of the Corporation's obligations, whether express or implied, and particularly of any other claim or breech of warranty contained in Paragraph A, or of any other warranties, express or implied, or claim of liability that might, despite Paragraph B, be decided against the Corporation by lawful authority, the Corporation's product for any purpose whatsoever. losses, or expense arising in connection with the use of, Corporation shall under no circumstances be liable for any consequential damages, losses, or expense arising in connection with the use of, or inability to use, the

of the original warranty only. An adjustment made under warranty does not void the warranty, nor does it imply an extension of the original 12-month warranty period. Products serviced and/or parts replaced on a no-charge basis during the warranty period carry the unexpired portion

If for any reason any of the foregoing provisions shall be ineffective, the Corporation's liability for damages arising out of its manufacture or sale of equipment, or use thereof, whether such liability is based on warranty, contract, negligence, strict liability in tort, or whether such liability is based on warranty. otherwise, shall not in any event exceed the full purchase price of such equipment.

must be commenced within one year after the cause of such hereunder or under any law applicable to the sale of equipment or the use Any action against the Corporation based upon any liability or obligation arising action arises thereof



Power PCB Relay

Power PCB Relay

G2R

Features

- Slim-styled power relay available in both latching and non-latching types
- Creepage distance of 7.874 mm (.31 in.) min. between coil and contact
- Single and dual-winding latching types available
- Plug-in and Quick-connect terminals available
- High-sensitivity (360mW), high capacity (16 A) and bifurcated contact types available
- Highly stable magnetic circuit for latching endurance and excellent resistance to vibration and shock
- Safety-oriented design assuring high surge resistance (15,000 V min. between coil and contact with the single-winding type; 10,000 V min. between coil and contact with the dual coil type)

Contact Data

Contact ratings

One-pole: General purpose: 10 A, 250 VAC, 30 VDC (Resistive); 7.5 A, 250 VAC, 5 A, 30 VDC (Inductive); 3 A, 120 VAC, Tungsten (TV-3); 1/3HP, 120 VAC; 1/2HP, 250 VAC; 1/2HP, 277 VAC

High-capacity: 16 A, 250 VAC, 30 VDC (Resistive); 8 A, 250 VAC, 30VDC (Inductive);

3 A, 120 VAC, Tungsten (TV-3); 1/3HP, 120 VAC; 1/2HP, 250 VAC High-sensitivity: 5 A, 250 VAC, 30 VDC (Resistive); 2 A, 250 VAC, 3 A, 30 VDC (Inductive) Latching: 5 A, 250 VAC, 30 VDC (Resistive); 3.5 A, 250 VAC, 2.5 A, 30 VDC (Inductive); 3 A, 120 VAC, Tungsten (TV-3); 1/6HP, 120 VAC; 1/2HP, 250 VAC

Two-pole:

General purpose: 5 A, 250 VAC, 30 VDC (Resistive); 2 A, 250 VAC, 3 A, 30 VDC (Inductive); 3 A, 120 VAC, Tungsten (TV-3); 1/6HP, 120 VAC; 1/3HP, 240 VAC

3 A, 120 VAC, Tungsten (TV-3); 1/6HP, 120 VAC; 1/3HP, 240 VAC High-sensitivity: 3 A, 250 VAC, 30 VDC (Resistive); 1 A, 250 VAC, 1.5 A, 30 VDC (Inductive) Latching: 3 A, 250 VAC, 30 VDC (Resistive); 1.5 A, 250 VAC, 2 A, 30 VDC (Inductive); 3 A, 120 VAC, Tungsten (TV-3); 1/6HP, 120 VAC; 1/3HP, 250 VAC

Contact material AgCdO

Maximum operating voltage 380 VAC, 125 VDC

Maximum operating current

One-pole: General purpose: 10 A High-capacity: 16 A High-sensitivity: 5 A Latching: 5 A **Two-pole:** General purpose: 5A High-sensitivity: 3A

Maximum switching capacity

One-pole: General purpose, Resistive: Unsealed – 2,500 VA, 300 W; Sealed – 2,000 VA, 240 W High-capacity, Resistive: Unsealed – 4,000 VA, 480 W

High-sensitivity, Resistive: Unsealed/Sealed – 1,250 VA, 150 W

Latching, Resistive – 1,250 VA, 150 W

Two-pole:

Latching: 3A

General purpose, Resistive: Unsealed – 1,250 VA, 150 W; Sealed –1,000 VA, 120 W High-sensitivity, Resistive: Unsealed/Sealed – 750 VA, 90 W Latching, Resistive – 750 VA, 90 W

Minimum permissible load

One-nole:

100 mA at 5 VDC

Two-pole:

10 mA at 5 VDC

mon services



A & & & & A

Coil Data [% of rated voltage]

Pickup voltage 70% max. (DC & High-Sensitivity DC); 80% max. (AC)

Dropout voltage 15% min. (DC & High-Sensitivity DC); 30% min. (AC)

Set voltage 70% max.

Reset voltage 70% max.

Maximum voltage 110% at 70°C

Characteristic Data

Initial contact resistance One-pole: 30mΩ max.

Two-pole: $50m\Omega$ max.

Operate time 15ms max. Release time

AC coil: 10ms max. DC coil: 5ms max.

Set time - Latching 20ms max.

Reset time - Latching 20ms max.

Insulation resistance 1,000MΩ min. (at 500 VDC)

Dielectric strength

One-pole:

Between coil and contacts: 5,000 VAC, 50/60 Hz for 1 minute Across open contacts of same pole: 1,000 VAC, 50/60 Hz for 1 minute Two-pole:

Between coil and contacts: 5,000 VAC, 50/60 Hz for 1 minute Between contact sets: 3,000 VAC, 50/60 Hz for 1 minute Across open contacts of same pole: 1,000 VAC, 50/60 Hz for 1 minute Latchina:

Between set and reset coils: 1,000 VAC, 50/60 Hz for 1 minute

Ambient temperature -40° to 70°C

Service life

Mechanical: AC coil: 10.000.000 operations min.

DC coil: 20,000,000 operations min.

Electrical: 100,000 operations min. for all resistive and inductive ratings with the following exceptions: One-pole, General purpose, Sealed: 8 A, 250 VAC, 30 VDC Two-pole, General purpose, Sealed: 4 A, 250 VAC, 30 VDC

Construction Data

Termination Plug-in, Quick Connect, and PCB terminals Construction Semi-sealed and Fully-sealed Weight .6 oz (17 g), Latching, Quick Connect Type: .71 oz (20 g) Packaging method Trays

CAN'T FIND THE PRODUCT SOLUTION YOU NEED? MANY OTHER STYLES AND VARIATIONS ARE AVAILABLE. CALL YOUR OMRON REPRESENTATIVE FOR MORE INFORMATION.

Power PCB Relay

Ordering Information

Part		Rated voltage	Coil res.		Contact	
number		(V)	(Unms)	Power	rating	Type
G2R-1 -	DC5	5 DC	47	530mW	10 A	SPDT
-	DC6	6 DC	68		10 A	PCB
-	DC12	12 DC	275		10 A	General
-	DC24	24 DC	1,100		10 A	Purpose
-	DC48	48 DC	4,170		10 A	Semi-Sealed
-	AC24	24 AC	260	0.9 VA	10 A	
-	AC120	120 AC	6,500		10 A	
-	AC240	240 AC	30,000		10 A	
G2R-14 -	DC5	5 DC	47	530mW	10 A	SPDT
indulting 5	DC6	6 DC	68		10 A	PCB
	DC9	9 DC	153		10 A	General
-	DC12	12 DC	275		10 A	Purpose
-	DC24	24 DC	1,100		10 A	Sealed
-	DC48	48 DC	4,170		10 A	
	AC12	12 AC	65	0.9 VA	10 A	
the key la	AC24	24 AC	260		10 A	
	AC120	120 AC	6,500		10 A	
-	AC240	240 AC	30,000		10 A	
G2R-1-E -	DC5	5 DC	47	530mW	16 A	SPDT
-	DC12	12 DC	275		16 A	PCB
-	DC24	24 DC	1,100		16 A	High-
-	DC48	48 DC	4,170		16 A	Capacity
-	AC24	24 AC	260	0.9 VA	16 A	Semi-Sealed
-	AC120	120 AC	6,500		16 A	
G2R-14-H -	DC5	5 DC	70	360mW	5 A	SPDT
en ist ist	DC6	6 DC	100		5 A	PCB
	DC12	12 DC	400		5 A	High-
-	DC24	24 DC	1,600		5 A	Sensitivity
			Section 1		100000	Sealed
G2R-1A -	DC5	5 DC	47	530mW	10 A	SPST-NO
-	DC6	6 DC	68		10 A	PCB
	DC12	12 DC	275		10 A	General
	DC24	24 DC	1,100		10 A	Purpose
						Semi-Sealed
G2R-1A4 -	DC5	5 DC	47	530mW	10 A	SPST-NO
	DC12	12 DC	275		10 A	PCB
	-DC24	24 DC	1,100		10 A	General
	AC24	24 AC	260	0.9 VA	10 A	Purpose
	AC120	120 AC	6,500		10 A	Sealed
G2R-1A-E	-DC5	5 DC	47	530mW	16 A	SPST-NO
	-DC12	12 DC	275		16 A	PCB
	-DC24	24 DC	1,100		16 A	High-
						Capacity
						Semi-Sealed
G2R-1-S	-DC5	5 DC	47	530mW	10 A	SPDT
	-DC6	6 DC	68		10 A	Plug-in
	-DC12	12 DC	275		10 A	General
	-DC24	24 DC	1,100		10 A	Purpose
	-AC12	12 AC	65	and the second	10 A	Unsealed
	-AC24	24 AC	260	0.9 VA	10 A	
	-AC120	120 AC	6.500		10 A	
	- 1 W - de W		-,			

Part number		Rated voltage (V)	Coil res. (Ohms)	Power	Contact rating	Туре
G2R-1-T	-DC5	5 DC	47	530mW	10 A	SPDT
	-DC12	12 DC	275		10 A	Quick
	-DC24	24 DC	1,100		10 A	Connect
	-AC24	24 AC	260	0.9 VA	10 A	Upper
	-AC120	120 AC	6,500		10 A	Mounting
						Bracket
						Unsealed
G2R-2	-DC5	5 DC	47	530mW	5 A	DPDT
	-DC12	12 DC	275		5 A	PCB
	-DC24	24 DC	1,100		5 A	General
	-AC24	24 AC	260	0.9 VA	5 A	Purpose
	-AC120	120 AC	6,500		5 A	Semi-Sealed
G2R-24	-DC5	5 DC	47	530mW	5 A	DPDT
	-DC6	6 DC	68		5 A	PCB
	-DC12	12 DC	275		5 A	General
	-DC24	24 DC	1,100		5 A	Purpose
	-DC48	48 DC	4,170		5 A	Sealed
	-AC24	24 AC	260	0.9 VA	5 A	
	-AC120	120 AC	6,500		5 A	31,12
G2R-24-H	-DC5	5 DC	70	360mW	3 A	DPDT
	-DC6	6 DC	100		3 A	PCB
	-DC12	12 DC	400		3 A	High-
	-DC24	24 DC	1,600		3 A	Sensitivity
12.512.57		-			C) extrem (C)	Sealed
G2R-2A4	-DC5	5 DC	47	530mW	5 A	DPST-NO
	-DC12	12 DC	275		5 A	PCB
	-DC24	24 DC	1,100		5 A	General
	-AC24	24 AC	260	0.9 VA	5 A	Purpose
	-AC120	120 AC	6,500			Sealed
G2R-2-5	-DC5	5 DC	47	530mW	5 A	DPDT
	-DC12	12 DC	275		5 A	Plug-in
	-DC24	24 DC	1,100		5 A	General
	-AC24	24 AC	260	0.9 VA	5 A	Purpose
	-AC120	120 AC	6,500		5 A	Unsealed
G2RK-1	-DC5	5 DC	47	850mW	5 A	SPDT
	-DC12	12 DC	275	(Set)	5 A	PCB
	-DC24	24 DC	1,100	600mW	5 A	Dual Coil
				(Reset)		Latching
						Semi-Sealed
G2RK-2	2 -DC5	5 DC	47	850mW	3 A	DPDT
	-DC12	12 DC	275	(Set)	3 A	PCB
	-DC24	24 DC	1,100	600mW	3 A	Dual Coil
				(Reset)		Latching
						Semi-Sealed

Note: 1. Other coil voltages available. Consult Omron.

G2R

13 (.51) max.

10 (.39)*

29 (1.14)

Dimensions [Unit: mm (inch)]

PCB Terminal: SPDT

(General Purpose, High Sensitivity)



Note: 1. For SPST-NO, standard version, remove terminal no. 2. 2. and :_____ indicate mounting orientation marks.

> 29 (1.14) max.

> > 0.3 (.012) 0.16 (.006) 0.5 (.020)

> > > 2.5

Note: 1. For SPST-NO, high-capacity version, remove terminal nos. 2 and 7.

ARE AVAILABLE, CALL YOUR OMRON REPRESENTATIVE FOR MORE INFORMATION.

2. and [_____] indicate mounting orientation marks.

Terminal arrangement/ Internal connections

PCB: SPDT High Capacity

25.5 (1.00)

> [0.3 (.012)]

4 (.16)

0.3 (.012)

Terminal arrangement/ Internal connections

(bottom view)







13 (.51) max

1 (.04)

Mounting holes

(bottom view)

2.1 (.08)

4.75 (19) 0.5 (02) 4.75 (19) 0.5 (02) (035x 12) 4 (16) (035x 12

29 (1.14)

> Terminal arrangement/ Internal connections (bottom view) G2R-1-S

1	-**
a 🕂	
5	

Note: 1. and !___! indicate mounting orientation marks.

Quick Connect: SPDT

Plug-in: SPDT

2.5 (0.1)

1 20 (.79)

ŧ



Terminal arrangement/ Internal connections (bottom view)







Note: 1. For SPST-NO, quick connect version, remove terminal no. 2.

OMRON 103

2.5 (.10)

8-1.3 (.05)

[2./ (.11)]

Power PCB Relay

Dimensions [Unit: mm (inch)]

PCB Terminal: DPDT

(General Purpose, High Sensitivity)



Terminal arrangement/ Internal connections (bottom view)



Plug-In: DPDT

20

6 (.24)

2.5 (0.1)

2 (.08)

8.9 (.35)

Terminal arrangement/

2 3

7 6

Note: 1. and ! _ ! indicate mounting orientation marks.

Internal connections

G2R-2-S

1

÷

8

(bottom view)



13 (.51) max.

10

 \mathbf{T}

4 (16

1 (.04)

13 (.51) max $\begin{array}{c} 29 \\ (51) \text{ max.} \\ 25.5 \\ (1.00) \\ \text{max.} 25 \\ (.01) \\ 4 \\ (.16) \\ 1.25 \\ (.01) \\ 1 \\ 1.04 \\ 1.04 \\ 0.16 \\ (.006) \end{array}$

Terminal arrangement/ Internal connections (bottom view)

SPDT Dual Coil Latching





Note: 1. For DPST-NO, general purpose and high-sensitivity versions, remove terminal nos. 2 and 7.

29 (1.14) max

UU

Т

0.5

0.5

٠

0

2.6

0.5 .

- 19.4 (.76) -

Note: 1. For SPST-NO, latching version, remove terminal no. 3. 2. and [__] indicate mounting orientation marks.

DPDT Dual Coil Latching



لروسیل ____الع ۱ (.04)

13 (.51) max

Terminal arrangement/ Internal connections G2R-2-S



(bottom view)

Mounting holes (bottom view)





Note: 1. For DPST-NO, latching version, remove terminal nos. 3 and 8. 2. and 1 in indicate mounting orientation marks.

b and Dial Plat Accessory Item Not Included)

-

For detailed instructions see Sec. III

0



TABLE 2. ELECTRICAL RATINGS

			RATING WITHOUT AUXILIARY HEATSINK			RATING WITH AUXILIARY HEATSINK		
NUMBER	AC LINE VOLTAGE (VAC)**	MOTOR VOLTAGE (VDC)	AC LOAD CURRENT (RMS AMPS)	DC LOAD CURRENT (AVG. AMPS)	MAX. HP	AC LOAD CURRENT (RMS AMPS)	DC LOAD CURRENT (AVG. AMPS)	MAX. HP
KBPB-125	120	90-130	12.0	8.0	3/4	24.0	16.0	11/2
KBPB-225	240	180	12.0	8.0	11/2	24.0	16.0	3

TABLE 3. GENERAL PERFORMANCE SPECIFICATIONS

Speed range (ratio)	50:1	CL/torque range (% full load)	0-200
Load regulation-armature feedback (0-full		Accel time range (0-full speed) (secs.)	.2-10
load, 50:1 speed range) (% base speed)	1*	Decel time range (full-0 speed) (secs.)	.2-10
Load regulation-tachometer feedback (0-full		Min. speed trimpot range (% full speed) .	0-30*
load, 50:1 speed range) (% set speed)	1*	Max. speed trimpot range (% full speed)	50-110*
Line voltage regulation-armature feedback		IR compensation trimpot range	
(at full load, ±10% line variation		(at specified full load) (volts)	0-24
(% base speed)	1/2*	Maximum allowable ambient temperature	
Line voltage regulation-tachometer feedback		at full rating (°C/°F)	45/113
(at full load, ±10% line variation		Tachometer feedback input volts	
(% set speed)	1/2*	(per 1000 RPM) (VDC)	7/50
Control linearity (% speed vs. dial rotation)	2	Maximum number of starts/stops or	
		reversals (operations/min.)	10**

is for 3% load regulation. To obtain supportor regulation, see Sec. III F, Chief ractory trimpot settings are as follows: CL-150% FL, Accel-1 sec., Decel-1 sec., MIN-(0)-speed, MAX-full speed & IR-6 volts. Rating is based on a brake time of (1) second. For increased operations per minute or longer brake time, consult factory.

INTRODUCTION The KBPB® Full Wave Solid State DC Motor Speed and Reversing Control represents the latest state-of-the-art design achievable through modern technology.

Features Include:

eatures Include: Integrated Circuitry Used to control and amplify command and reference levels with both closed and open loop teedback to provide superior motor regulation. (Speed changes due to load, line voltage, or temperature variations are held to minimum levels.) Selected and tested for proven dependability. Tensiont Protection

- Used to prevent failure of the power bridge circuit caused by voltage spikes on the AC line. Transmit From the second and the power bridge circuit caused by voltage spikes on the AC line. High Reliability When used in accordance with the instructions included in this manual, the KBPB® will provide When used in accordance with the instructions included in this manual, the KBPB® will provide the second sec

SECTION I. APPLICATION INFORMATION

SECTION I. APPLICATION INFORMATION A. Motor Type. The KBPB® is designed for Permanent Magnet (PM) and Shunt Wound D.C. motors. Controls operated on 120 volt AC inputs are designed for 90 volt SCR rated motors. Controls operated on 240 volt AC inputs are designed for 180 volt SCR rated motors. Use of higher voltage motors will result in degradation of full speed performance. Also, if motor is not an SCR rated type, the actual AC line amperage at full load should not exceed the motor's DC nameplate rating. B. Torgue Requirements. When replacing an AC induction motor with a DC motor and speed control, consideration must be given to the maximum forque requirements. The full load otorque rating of the DC motor must be given to the maximum lorque requirements. The full load otorque rating of the DC motor must be given to the maximum lorque requirements. The full load otorque rating of the DC motor must be given to the maximum lorque requirements. The full load should not C. Acceleration Start. The KBPB® contains an adjustable acceleration start feature which allows the motor to smooth accelerate from 0-full speed over a time period of .2-10 seconds. The "ACCEL" is factory set at 1 second. the motor to smoothly accelerate from 0-full speed over a time period of .2-10 seconds. The "ACCI is factory set at 1 second. D. Limitations in Use. The KBPB®controls are designed for use on machine applications.

E. Switching Applications: KBPB^{rep}contains the KB APRM[®] which is designed to provide anti-plug instant reverse, solid state dynamic brake and rapid cycling. The maximum recommended number of run-brake cycles is 10 per minute. If higher rates are required, contact our sales dept CAUTION: Consult factory before using on constant horsepower applications such as saws or drill presses. Do not use in explosive atmosphere.

(7) Plug-in Horsepower Resistor® (supplied separately)
(8) "Brake" LED
(9) Armature Fuse (supplied separately)

CAUTION: Be sure the KBPB "Is used within its max ratings. Follow all installation instructions carefully. (Reference Section II.)

MOTOR HORSEPOWER RANGE*

Voltage

1/50-1/30

1/30-1/20

1/20-1/12

1/20-1/12 1/12-1/8 1/8-1/5 1/4

1/3

1/3

3/4

-1/2**

Armature Voltage 180V DC

1/25-1/15

1/15-1/10

1/10-1/6

1/6-1/4

1/4-1/3

3/4

1-1/2 2***

Barrier Terminal Block
 Ac Line Fuse (supplied separately)
 Trimpots: Min, Max, CL, IR
 Trimpots: Accol, Decel
 Trimpot: Aux Speed
 Dynamic Brake Resistor

Plug-in Horsepowe Resistor® Resistance Value (Ohm

35

.25

18

.05

.035

.025

.015

006

Motor horsepower and armature voltage must be specified when ordering so that proper resistor will be supplied. For overapping motor horsepower range use lower value Plug-In Horsepower Resistor. Availary heatishk must be used to achieve HP rating. FIG. 1 FEATURES AND FUNCTIONS

KB P/N 9833

9834

9835

9836

9837

9839

9840

9841

9842 9843

9850

Ð

TOP VIEW APRM® (natented)

BOTTOM VIEW Speed Contr

SECTION II. INSTALLATION INSTRUCTIONS A. Location and Mounting. The KBPB control should be mounted on a flat surface and located in an area where it will not be exposed to contaminants such as water, metal chips, solvents or more relievely the future. excessive vibration.

excessive violations: When mounting in an enclosure the air space should be large enough to provide adequate heat dissipation. The maximum allowable ambient temperature at full rating is 45*C/113*F. Consult factory if more information is required. * Warning: Do not mount control with terminal block legand facing down. (Relay Plunger down.)

FIG. 2 MECHANICAL SPECIFICATIONS (inches)







TABLE 6. ARMATURE FUSE CHART

	FUSE	APPROX. DC MOTOR	180VDC MOTOR	90VDC MOTOR
	(AC AMPS)	SEPOWER (AMPS)		HORSE
	1/2	.33	1/15	1/30
	3/4	.5	1/10	1/20
	1	.65	1/8	1/15
	1-1/4	.85	1/6	1/12
NOT	2	1.3	1/4	1/8
A A	2-1/2	1.7	1/3	1/6
1. A	4	2.5	1/2	1/4
1	5	3.3	3/4	1/3
	8	5.0	1	1/2
2	12*	7.5	1-1/2	3/4
E.	15	10.0	2	1
	25*	15.0	3	1-1/2

ACL line Fuse is chosen according to the maximum rating of the control: 12 Amp fuse for all motors up to 34 HP-90V and 1½ HP-180VDC. 25 Amp fuse for all motors 1 and 1½ HP-90V and 2 and 3 HP-180VDC. Use Buss ABC, Litt. 326 ceramic lives or cenuisatent) fuse or equivalent.)

2. Armature Fuse can be chosen in accordance with the fuse chat. Note: The armature fuse is calculated based on the approximate full load DC current rating of the motor times a form fac-tor of 1.5. If motor has characteristics not consistent with these approximations, a different fuse value may have to be used. Fuses are available from your distributor. Also available is a Fuse Kit (KB Part #9870) containing 700 assorted fuses.

10

12

A. Acceleration Start. The ACCEL is factory set at approx. 1 second. To readjust to different times, set the knob to the desired position as indicated in Fig. 4.
B. Deceleration. The DECEL is factory set to provide minimum ramp-down time. To increase the ramp-down time adjust the DECEL trimpot as indicated in Fig. 4.

C. Maximum Speed Adjustment. Turn Speed Control Knob to full speed (maximum CW posi-tion). Adjust max. speed trimpot to new desired setting.

NOTE: Do not attempt to adjust the max, speed above the rated motor RPM since unstable motor operation may occur. For moderate changes in the max, speed, there will be a slight effect on the min, speed setting when the min, speed is set a zero. There may be a significant variation in the min, speed setting if the min, speed is at a higher than zero setting.

D. Minimum Speed Adjustment. If a higher than zero minimum speed is desired, readjust the minimum speed by luming the speed control knob to zero setting (full CCW position). Then ad-just the min. speed rimpol to the desired setting.

NOTE: The min. speed adjustment will affect the max, speed setting. Therefore, it is necessary to readjust the max, speed after the min, speed, and it may be necessary to repeat the sequence until both the min, and max, speeds are set to desired levels.

E. Current Limit (CL/Torque Adjustment). CL circuitry is provided to protect the motor and con-trol against overloads and demagnetization of PM motors. The CL also limits the inrush current to a safe level during startup. The CL is factory set to approximately 15 times the full load rating of the motor. (CL trimpot is nominally set to approx. 65% of full CW rotation.) NOTE: The correct value Plug-in Horsepower Resistor® must be installed in order for the CL and IR comp. to operate

set the CL to factory specifications adjust as follows:

Set speed control knob at approximately 30–50% CW rotation. Set CL trimpot to full CCW position.
 Connect a DC ammeter in series with the armature lead.



ARM

55

Jog or Run speed, either in Forward or Reverse direction. (DECEL Trimpot does not affect the brake time.) In order for the KBPB control to drive a motor S, and S, must be connected together for Forward and S, and S, must be connected together for Reverse. If no connection is made to S, the control will be a "Brake" mode. The brake circuit consists of an SCR and dynamic brake resistor (RB). An LED indicator on the APRIM[®] shows that power is applied to the SCR gate. If brak-ing is not required, the wire to RB may be disconnected. (Note that the LED will still light with RB disconnected. (Note NHIEHT[®]: Terminals I, and I₂ provide an Inhibit[®]Innoting the I, and I₂ terminals together. When installing the KBPB be sure to follow the mounting and wiring instructions found in Sec. II.

NOTE: When switching terminals Si, Si, Si, approximately time of current with full motion values must be present of their terminals (I, J, P, P, P, and S) are low values or be obtained to their but line values to ground. Any switch or raily can be used for switchings are ground. Any switch must be opened before S₂ and S₃ are closed and vice versa.

The following wiring diagrams are presented to demonstrate the capabilities of the KBPB. A Forward-Brake-Reverse with Single Poten-tiometer. Use an SPDT ON-OFF-ON switch. Clase S₁ and S₅ for motor tor run in FWD direc-tion. Open S₅ for Brake. Close S₂ and S₅ for motor to run in Reverse direction. If Brake posi-tion is not required, an SPDT (non-center OFF) may be used. This provides instant Anti-plug Reversing.





CAUTION: Do not bundle control wires P1, P2, P3, I1, I2, S1-S4 with line or motor leads. If wires are over 18*, use

C. Voltage Following. All models can be controlled with an **isolated** analog reference voltage (0–9VDC) in lieu of the main speed potentiometer. The voltage is connected to $P_2(+)$ and F_{--} the control output voltage will linearily (blow the input voltage. The source impedance of the input should be 10K ohms or less. The Min trimpot can be used to provide an offset is not fost is not required adjust the Min to 0– or O– speed as desired. The Max trimpot is rendered inoperative in the voltage following mode. Use auxiliary trimpot to limit the control range. If the input signal is not isolated, or is a current signal (4–20m), the KBS-L20O Signal Isolator must be used. It will allow direct connection to process controllers and microprocessors.

CAUTION: 1. The voltage leading P₂ and F₋ must be isolated from the AC line. Do not ground P₂ or F₋ to set a series or ground reference. 2. Do not bundle signal wires or P₂ and F₋ with AC line or motor connections. If signal wires are over 19°, use shielded calles.

D. Fusing. The KBPB™has provision for a built-inAC line fuse and armature fuse. The AC line fuse protects the control against catastrophic failure. If the fuse blows, the control is miswired, the motor is shorted or grounded, or the KBPB ⊡control is detective. The armature fuse provides overload protection for the motor and control. Choose the proper size armature fuse by multiplying the maximum dc motor amps by 1.7. NOTE: Be sure to fuse each angrounded AC line supply conductor. Do not fuse neutral or grounded conductors. All fuses should be normal blow ceramic 3AG, ABC or equivalent. (See Table 6 on page 10)

SECTION III—ADJUSTMENTS AND CONTROL FUNCTIONS—See Safety Warning Page 18 The KBPB has been factory adjusted to provide 0-full speed using the speed control knob. Minimum and Maximum speed trimpots are provided to change the speed from other than 0-full speed. The Acceleration (ACCEL) trimpot is provided to allow for a smooth start over an adjustable time period each time the AC power is applied or the speed pot is adjusted to a lower speed. Note: if P₂ is connected to P₄, or the enable lead, P₂, is opened, the control will ramp down to the MIN speed trimpot, setting. It is shorted to U₄, the control will coard down to zero speed. Note: if the full content of tramp-down time when the speed point is adjusted to a lower speed. Note: if P₂ is connected to P₄, or the enable lead, P₂, is opened, the control will ramp down to the MIN speed trimpot, setting. It is shorted to U₄, the control will coard down to zero speed. The CUr-rent Limit (CL, or torque output) adjustment is factory adjusted to provide excellent motor requisition under normal operation. The KBPB contains the KB APRIM[®] which provides anti-plug "instant" roverse and solid state dynamic braking. The APRIM[®] contains a trimpot which is used to preset a fixed speed for either the forward or reverse direction (see KBPB connection diagrams for additional information).

ormation), NOTE: In order for the IR comp and CL trimpot settings to be correct, the proper Plug-in Honsepower Resistor® must be installed for the particular motor and input voltage being used. Do not attempt to change the settings of the trimpost unders absolutely necessary since they are factory adjusted to near orginium settings.

RAPED & SEC.

The following procedure, presented in order of adjustment sequence, should be used when read-justing all trimpot functions: FACTBER SETTING 1 SEC.

Fig. 4 ACCEL/DECEL TRIMPOT ADJUSTMENT CAUTION! (PM motors only). Adjusting the accel time below 5 seconds increases inrush current. It may be necessary to measure the peak inrush current and consult with motor man-ufacturer since field magnet demagnetiza-tion may occur.



ç

Lock shaft of motor (be sure CL pot is in full CCW position). Apply power and rotate CL pot CW slowly until DC ammeter reads 1.5 times motor rating (do not exceed 2 times motor rating). NOTE: If only an AC ammeter is available, it can be installed in series with AC input line. Follow above instru however, set AC amperage at .75 times motor rating.

F. IR Compensation Adjustment. IR compensation is provided to substantially improve load regulation. If the load presented to the motor does not vary substantially, the IR adjustment may be set at a minimum level (approximately 40 full setting). The control is factory adjusted to approximately 3% regulation. If superior performance is desired (less than 1% speed change of base speed from 0 to full load), then the IR comp. should be adjusted as follows:

NOTE: Excessive IR comp. will cause control to become unstable, which causes motor cogging.

Set IR comp. trimpot at approximately 25% of CW roation. Run motor unloaded at approximately % speed and record RPM.
 Run motor with maximum load and adjust IR comp. trimpot so that the motor speed under load equals the unloaded speed per step 1.
 Remove load and recheck unloaded RPM. If unloaded RPM has shifted, repeat procedure for more serie trenulation.

more exact regulation.

The KBPB is now compensated to provide minimal speed change under large variations of apolied load

SECTION IV. KBPB APPLICATION INFORMATION

The KBPB is designed to offer a variety of switching functions. The APRM[®] module is the inter-face between command signals and the KBMM speed control module. By using terminals S₁, S₂ and S₃ the KBPB can be made to perform the following functions: Run-Brake, Forward-Brake Reverse and Forward-Reverse (instant anti-lug reverse). Terminal S₂ is used to supply a con-trol voltage which is adjustable with the APRM[®] trimpot R11. This voltage is used to supply a

B. Forward-Brake-Reverse with Adjustable Reverse Speed. Reverse speed is adjustable with the trimpot on the APRM* board. Use a DPDT ON-OFF-ON switch. In the Forward direc-tion, the remote speed pot is used. In the Reverse direction, P, is connected to S₄ for speed adjust-ment. If Brake position is not required, a DPDT switch (non-center OFF) may be used. If, while in Forward or Reverse position, a separate Brake function is required, S₅ may be interrupted using a limit switch or relay. (For remote reverse speed pot adjustment, see Wining Diagram C) C. Forward-Brake-Reverse with Run-Brake-

C. Forward-Brake-Reverse with Run-Brake-Jog. Jog speed is adjusted with remote speed pot. For SW1 use an SPDT ON-OFF-ON witch. For SW2 use DPDT ON-OFF-ON with momentary return from Jog position. (For non-remote Jog speed use trimpot on APRM®, see Wiring Diagram B).

Diagram B). D. Run-Brake-Jog with Adjustable Jog Speed. The Jog speed is adjustable with the trimpot on the APPM* board. Use a DPDT ON-OFF-ON switch. In the Hun mode, the external 5K speed pot is used. In the Jog mode P₂ is connacted to S₄ and the Jog pot, located on the APRM*, is used for speed adjustment. If Brake position is not required, a DPDT switch (non-center OFF) may be used. If, while in Forward or Jog position,





ARM LO

a separate Brake function is required, S₂ may be interrupted using a limit switch or relay. (For remote reverse speed pot adjustment, see Wining Diagram C.) E. Isolated Input for S₁, S₂, S₃. An isolator board Si-3i available as an accessory, it allows the KBPB forward-brake-reverse function to be activated by an analog signal. The Si-3 in installs by removing the 4-pin connector on the APRM. Install the Si-3 on the 4-pin header and plug the mating connector into the SI-3.

The SI-3 is activated by applying an analog voltage of 5-10VDC to terminals S_n, S_2 for forward, or S_3, S_2 for reverse. The KBPB with the SI-3 option is suitable for operation with programmable (voltage following input Model KBSI-240 Signal Isolator mable controllers. For complete isolation of the

should also be used.

DIA D -----

> QUN BRK

8-8

Lo 0-106

sui

POT



6

G. Enable. Control can be made to start and stop electronically with Enable. This circuit is "make to run" which is opposite of Inhibit .

Stop time is adjustable with DECEL trimpot. To obtain 0 speed when Enable is open MIN speed trimpot must be set to 0 speed. Two-speed operation can be obtained by setting the MIN speed to the desired level ENABLE CHAKE TO RUND



SA SPELD PUI SAFETY WARNING-PLEASE READ CAREFULLY This product should be soviced by a qualified tohnolican, electrical maintenance personnel familiar with its operation and the hazards involved. Proper installation (see instruction information which accompanies produ-cut), which includes writerin, mounting in proper enclosule, fusing or other overcurrent protection and grounding, can reduce the chance of electric shocks, fires or explosion in this product or products used with this product, such as electric motocial material submiolica and anterials (plastics, metals, carron, slicen, etc) which may be a poin-al reaction prover. This product is constructed of materials (plastics, metals, carron, slicen, etc) which may be a poin-al mascel from chain material submiolica and the product core request. Progra the long, prounding affect sensitive electronic exponent. If information is required on this product, solid factory it is the respon-sibility of the equipment nanulucturer and individual installer to supply this safety warming to the ultimate user of this product. (SW effective 3/88).

18



20



F Tachometer feedback (DC tachs only). The load regulation of the control can be improved to 1% of sot speed over a 50:1 speed range by use of tachometer feedback. Since no provision made for the tach input on the terminal block, the tach positive connection must be made directly to the B or T terminal on the speed control module. NOTE: if control is used on a reversing ap-plication, the tach wires must also be reversed so that positive (+) is always connected to B or T. To set control for tachometer feedback.

T. To set control for tachometer feedback: (1) For tach feedback, cut jumper J1 on Printed Circuit Board. (Note: On Model KBPE-252, J1 is an B2K resistor) (2) Connect (tach as follows: (a) 7 voits/1000 RPM Connect (+) lead to Terminal "T" Connect (-) lead to Terminal "B"-(b) 50 voits/1000 RPM connect (-) lead to Terminal "B"-Connect (-) lead to Terminal "B"-Note: The tachometer voitage in upus to based on 1200 RPM motors. For than 1,500 RPM, or for tachometer voitages other than what is specified, an external tachometer resistor must be used. Install the resistor (RY) in series with positive (-) labort to Terminal "public transformation". The example of the resistor (RY) in series with positive (-) labort to Terminal Tachometer resistor must be used. Install the resistor (RY) in series with positive (-) labort the resistor voitage in voitance of RT may be calculated using the following formula. RT = 12.66 x Vy X S - 15300] Vy r = Tachometer voitage in voitar1000 RPM



H. Overload Protection The KBAP-240D is a multipurpose DC Current Sensing Relay and Over-load Protector. It is specifically designed for use with DC motors and speed controls from 1/8-3. HP. The unit can be used with largor or smaller motors by utilizing the external method of con-nection. KBAP-240D operates by sensing current in the armature circuit. When the preset level is reached, an output relay trips. An adjustable time delay (2-15 sec.) is incorporated, which eliminates nuisance tripping. Manual or automatic reset is provided at the user's option along with an LED, which indicates when the preset current level has been reached. In addition, a Hys-teresis trimpot is provided which can be used to increase the differential between the pull-in and drop-out points of the output relay. When an overload occurs, the KBAP-2400 can be used to shut the system down, sound an alarm, or initiate corrective action before damage occurs. 12(25/10/15/20), which can be further adjusted with a built-in trimpot. See page 20 for connection diagram. diagram

REVERSING APPLICATIONS. The KBAP set for Internal Sensing is suitable for unidirectional cur-rent only. Therefore, reversing controllers utilizing relays or reversing modules cannot be con-nected directly to the KBAP For those applications the KBAP must be connected between the speed control and reversing module. For external Sensing the KBAP can be connected directly to the reversing control. See Fig. for correct connection diagrams (used for KB Models KBPB and KBCC-R suffix). See page 20 for connection diagram.

19

17

SECTION V. TROUBLESHOOTING GUIDE

ubleshooting Guide is intended for use by a qualified technician. The Guide is designed to isolate com-s of the KBPB and/or motor. It should be used with the parts lists and schematics contained in this manual.

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
1. Motor does not run.	1. AC voltage not brought to L1, L2	1. Correct wiring to control.
	2. Blown line or armature fuse.	 Replace blown fuse with property rated 3A8-type. If fuse blew due to miswiring, speed control module may be defective.
	 Speed control knob set to 0 	3. Turn knob CW to start motor.
	A Deletive motor	4. Check for defective motor worn
	 Delective motor. Dive la bioreannuar Basistor ant 	brushes etc. Beolace motor.
	installed.	5. Install proper size Plug-In Horsepower Resistor
Motor hums, or runs at very low speed (with control knob set at	1. Low voltage.	 Check line voltage at control and rewire as required.
high number) or motor slows	Overload condition: control in current	
down substantially when load is	limit mode (CL)	Reduce loading; CL trimpot setting
applied.	(trimpot not set correctly).	may have to be increased. See Section IV.
	 Plug-in Horsepower Resistor not correct size. 	Install proper size resistor.
	 Incorrect wiring. Armature and shunt connections interchanged (abunt motor only) 	 Correct wiring (armature has lower resistance than field).
3. Erratic motor performance	1. Defective motor, worn brushes etc.	1. Repair motor.
a crime motor personneree.	2 Overload condition	Remove overload.
	 Plug-in Horsepower Resistor wrong size. 	Replace with proper size.
	 IR comp and/or CL trimpots not set property. 	 Readjust trimpots as per Section IV.
	Defective speed control module.	Replace module.
 Motor continues to run when speed control knob is set to 0. 	 Min speed trimpot not set to full CCW position. 	 Readjust min. trimpot.
	2. IR comp trimpot set too high.	Lower IR comp trimpot setting.
5. Motor will not run in either for-	1. Incorrect wiring or faulty reversing	 Correct wiring. See KBPB connec-
ward or reverse direction	switch	tion diagrams.
	2. Defective APRM*	2. Replace APRM [®]
6. No Braking action in brake mode.	 Incorrect wiring. 	 Correct wiring.
	Defective brake resistor.	Replace resistor.
	3. Defective APRM [®]	3. Replace APRM*
Motor runs in wrong direction.	1. Armature leads reversed.	 Reconnect armature leads.
the second se		

SECTION VI. (B) SPEED CONTROL MODULE SCHEMATIC*





KBPB Operating Instructions

57

DIGITAL TACHOMETER SENSOR KITS

POWER/MATION

W238 N 1690 Rockwood Drive Waukesha, WI 53188 Phone: (414)523-0600 800-242-2060 Fax: (414) 523-0611

SPECIFICATIONS

INPUT: 5-16VDC OUTPUT: NPN, 20ma TEMPERATURE: Minus 40°F to plus 225°F OUTPUT CONNECTION: Three Wire PULSES PER REVOLUTION (ppr): 1 * WAVE FROM: Square Wave ENVIRONMENT: Impervious to dust, oil & water * 2, 15 & 60 ppr models are available



ORDERING CHART

		DIMENSIONS				
MOTOR FRAME SIZE	KIT MODEL NUMBER	A	В	C	D	E
56C	DTK-056 M1	9.375	5.875	4.500	7.875	5/8"
143TC, 145TC, 182C & 184C	DTK-184 M1	9.375	5.875	4.500	7.875	5/8"
182TC, 184TC, 213C, 215C & 254C	DTK-215 M1	12.312	7.250	8.500	10	1-1/8"
213TC, 215TC, 254UC & 256UC	DTK-254 M1	12.312	7.250	8.500	10	1-3/8"
254TC & 256TC	DTK-256 M1	12.312	7.250	8.500	10	1-5/8"

NOTE: Kits consist of motor face ring, sensor, mounting bolts and sensing wheel.



NOTE: To interface sensor to controller, use a shielded triple (18-22 AWG) with bare drain wire, such as Belden 8772.

To Reset

1/16

1/8 1/4 3/8 1/2 3/4

1-1/2

3

5

6



rotating reversing equipment.

The limit switch input shaft is connected to a worm gear. Adjustable self lubricating nylon roller cams are concentrically mounted to the worm gear. These adjustable cams actuate the precision limit switches by utilizing a lever assembly.

....

INSTALLATION

This limit switch may be mounted in any convenient position. When installed this limit switch will provide long life with a minimum amount of service maintenance.

The following recommendations will prove helpful.

- 1 Install the limit switch so that the shaft load will not exceed (5) five pounds.
- 2 A flexible coupling is recommended for all installation other than gear drive application.
- 3 Coupling should be employed in a manner that results in a minimum of thrust loading on the shaft. If switches are mounted with the shaft up or down, some additional thrust loading resulting from the weight of the shaft plus a very light coupling is permissible.
- 4 Whenever possible, a separate support bearing for the drive sprocket should be used.
- 5 Permissible speed of the input shaft 2000 R.P.M.

LUBRICATION

This limit switch was lubricated at the factory and should not require lubrication for the life of the switch.

ADJUSTMENT

Refer to figure 1. The electrical switch units "G" and "H" are shown with the contact positions assumed when the cams are not actuating the switch units.

When the cam rotates and actuates the switch, the "B" (closed) contact opens and the "A" (open) contact closes. Each precision switch has (1) one independent adjustable cam.

TO ADJUST SWITCH "G"	TO ADJUST SWITCH "H"	WARNING
1. Loosen Red Set Screw	1. Loosen Blue Set Screw	LOOSEN CAN SET SCREW BEFORE
2. Turn "C" to Trip "G"	2. Turn "D" to Trip "H"	ADJUSTING OR DAWAGE OF CAMS
3. Tighten Red Set Screw	3. Tighten Blue Set Screw	WILCCOUR

When ordering Renewal Parts give this form No. PF-046, Item No., Description, Part No., Quantity, and the Complete Unit Number stamped on the label. Reference FIG. #1 and FIG. #2 above.

ITE	M DESCRIPTION	PART NUMBER	QTY	1.
1	Case and Shaft assembly		1	
·	5:1 Ratio	PSD-0091300-DN		
	10:1 Ratio	PSD-0091400-DN		
	20:1 Ratio	PSD-0091500-DN		
	30:1 Ratio	PSD-0091600-DN		
	40:1 Ratio	PSD-0091700-DN		
	60:1 Ratio	PSD-0091800-DN		
	80:1 Ratio	PSD-0091900-DN		
	120:1 Ratio	PSD-0092000-DN		
2	Cam block & Worm Gear assy.		1	
	5:1 Ratio	PSD-0090500-DN		
	10:1 Ratio	PSD-0090600-DN		İ
	20:1 Ratio	PSD-0090700-DN		
	30:1 Ratio	PSD-0090800-DN		1
	40:1 Ratio	PSD-0090900-DN		
	60:1 Ratio	PSD-0091000-DN		
	80:1 Ratio	PSD-0091100-DN		
	120:1 Ratio	PSD-0091200-DN		
3	Shim Cam Block (.080 THK.)	PS-0003300-A	1	1
4	Shim Cam Block (.020 THK.)	PS-0000800-A	1	i
5	Shim Cam Block (.016 THK.).	PS-0003200-A	2	I
6	Limit Switch Standard SPDT	1950-1-A-B-DO	2	l
	Optional D.P.D.T.	1950-4-A-B-DO		
	Optional S.M.S.B.	1950-1408		
7	Adjusting Bracket Assembly	PSD-0024600-B	1	
8	Gear and Roller Assembly	PSD-00904-00-A	2	
9	Spring Compression	PM-0018000-A	2	
10	Lever Assembly	PSD-0024400-A	2	
11	Cover	PC-0069100-A	1	
12	Cover Gasket	PS-0000900-A	1	
13	Spacer Center Post	M-0073000-A	1	
14	Woodruff Key (#404)	04-564019-DN	1	

FORM PF-046 REV. "A" 10/94 OCT. 1990



Eurostrips

Research Concepts, Inc. • 9501 Dice Lane • Lenexa, Kansas • 66215 • USA

Electric Heater Elektrisches Heizgerät Réchauffeur élétrique





English





Electric Heater

Research Concepts, Inc. • 9501 Dice Lane • Lenexa, Kansas • 66215 • USA

your application.

condition.

÷

N.

÷

English

English

4 mm

mm 25

4.00 6.00

e

28359001

N

This heater can only be installed in a totally enclosed metal

enclosure.

EASi 4.5 Meter Antenna Installation Kit

1 Introduction

This document describes an installation kit that is used in conjunction with the RC2K90INT-2E interface box which allows an RC2000 antenna controller to operate an EASi 4.5m meter antenna. Efficient Antenna Systems inc. (EASi) may be contacted at <u>WWW.EASiSat.COM</u>. The EASi antenna uses 1 ½ HP 90 VDC motors, so the larger version of the interface box is used. The heater option is normally included in this version. The following issues are addressed in this paper:

- The AC power requirements of the interface box.
- Recommended types of cable that may be used to connect the RC2000 antenna controller to the interface box.
- A controller interface box antenna wiring diagram.
- RC2000EASi software configuration parameters.
- A conduit/wiring schedule.
- A Bill of Materials.

2 AC Power

The interface box is housed in a NEMA 4 weatherproof enclosure. In the Standard configuration, 120 Volt AC power must be provided at the antenna pad. All ungrounded AC line supply conductors must be fused or protected with circuit breakers, do not fuse neutral or grounded conductors. A 25 or 30 amp circuit breaker is sufficient. In addition, an AC emergency disconnect conforming to the NEC (National Electric Code) and other applicable electrical codes must be provided at the antenna and be readily accessible to personnel in the vicinity of the antenna.

The AC line input of the interface box will be pre-wired with 10 feet of 12/3 cable. The interface box has a straight 1/2" conduit fitting appropriate for flexible steel reinforced liquid tight conduit of which 8 feet is supplied. The user should make provisions to accept this type of conduit on the electrical box which houses the emergency disconnect. Alternatively, the user can replace the liquid tight conduit fitting with a different type of conduit fitting. The interface box is punched with a 7/8" diameter hole for the liquid tight conduit fitting.

3 Antenna Controller to Interface Box Interconnect Cable

The user must supply the cable to connect the RC2000 to the interface box. On the interface box there is a CN-GY-RB-3704 RACO 1 inch cable compression fitting reserved for mechanically connecting the interconnect cable to the interface box. The conduit fitting has a 0.85" to 1.00" diameter opening which the interconnect cable must pass through to enter the interface. Make sure that the interconnect cable(s) selected will fit through the opening. Alternatively, the user can replace the liquid tight cable fitting with a different type of conduit fitting. The interface box is punched with a 1.37" diameter hole for the cable fitting. This hole is appropriate for 1 inch conduit.

The cable must have 2 pairs of 20 AWG (or heavier) conductors to carry the motor control signals (forward - stop - reverse). Shielded conductors are not necessary for these signals but if shielded conductors are available the shield can be used. For shielded motor control conductors, follow the rules given below for the shielded sensor cables. In addition to the motor control signals a pair of individually shielded triples with drain wires are necessary for the sensor connections.

Please note the following concerning the interconnect cable and sensor connections ...

- Always use shielded cables for the sensors.
- The shield drain wire should only be connected at the RC2000.
- If the cable is spliced, be sure to splice the drain wire.
- Don't allow the shield or drain wire to come in contact with ground anywhere. If the cable insulation is cut at a splice put a piece of heat shrink over the frayed shield to keep it from coming in contact with ground.
- When splicing the sensor cables please refer to figure 7 in the RC2K90INT manual.

Belden 1083A cable has been successfully used to interconnect the RC2000 to the RC2K90INT-1 interface box. This cable consists of 4 individually shielded triples (or triads). The conductor size is 20 AWG and the shields are equipped with a drain wire. A similar product is available from Olympic Wire and Cable Corp. (part number 9883).

It also possible to use a pair of satellite TVRO 'actuator cables' to connect the RC2000 to the interface box. Actuator cable typically consists of a pair 16 AWG unshielded conductors and a shielded 22 AWG triple with drain wire. This cable is inexpensive and is available from Research Concepts, Inc. and EASi.

The RC2000 to interface box interconnect cable carries DC voltages of 40 volts or less. In the US a direct burial type cable may be used.

4 Making the Connections

The installation kit includes steel reinforced liquid tight flexible conduit and cabling for connection of the interface box to the antenna motors, sensors, limit switches and AC power. There are five straight conduit fittings, one cable-compression fitting, and two multi-cable clamp fittings on the bottom of the interface box. From the left, these fittings are used for: AC power, the RC2000 interconnect cable, the elevation motor conduit run, the azimuth motor conduit run, the azimuth sensor conduit run, and the elevation sensor conduit run.

Description of Conduit Run	Conduit Run Starting Point and Conduit Fitting Type	Conduit Length and Type	Cable Type/Length	Conduit Run Termination Point and Fitting Type
Azimuth Motor	Interface Box, CN- GY-4Q50 Straight Fitting	CDT-M-0_5 LQT 132 Inches	W-16AWG-Black, White, Green 156 Inches	Azimuth Motor, CN-GY-4Q50 Straight Fitting
Elevation Motor	Interface Box, CN- GY-4Q50 Straight Fitting	CDT-M-0_5 LQT 108 Inches	W-16AWG-Black, White, Green 180 Inches	Azimuth Motor, CN-GY-4Q950 90 Degree Fitting
Azimuth Sensor	Interface Box, CN- GY-4Q50 Straight Fitting	CDT-M-0_5 LQT 108 Inches	W-16AWG-Black, White, CBL-3_20- SHLD 132 Inches	Azimuth Sensor, CN-GY-4Q950 90 Degree Fitting
Azimuth Limit Switch	Azimuth Sensor, 90 Degree Fitting	CDT-P-0_5 LQT 24 Inches	The Continuation of W-16AWG- Black, White, Green Described in the Previous Entry.	Azimuth LimitSW, CN-GY-4Q950 Straight Fitting. Note: A 1/2" to ³ /4" Conduit Bushing is Required at the Limit Switch

There are six conduit runs that are used to connect the interface box to the antenna. The following table describes the conduit fitting types, conduit lengths, and cable types and lengths

EASi 4.5m Antenna Installation Kit

Description of Conduit Run	Conduit Run Starting Point and Conduit Fitting Type	Conduit Length and Type	Cable Type/Length	Conduit Run Termination Point and Fitting Type
Elevation Sensor	Interface Box, CN- GY-4Q50 Straight Fitting	CDT-M-0_5 LQT 180 Inches	CBL-2_18-SJO W-16AWG, Black, White 144 Inches	Azimuth Sensor, CN-GY-4Q950 90 Degree Fitting
Elevation Limit Switch	Elevation Sensor, Straight Fitting	CDT-M-0_5 LQT 24 Inches	The Continuation of CBL-2_18-SJO Described in the Previous Entry.	Azimuth LimitSW, CN-GY-4Q950 Straight Fitting. Note: A 1/2" to ³ 4" Conduit Bushing is Required at the Limit Switch

The antenna will be shipped with five flexible conduit runs (with wire pulled through the conduit) to the AC Disconnect, elevation motor, elevation sensor, azimuth sensor, and azimuth motor attached to the interface box. The installer will have to attach these conduit runs to the elevation motor, elevation sensor, azimuth sensor, and azimuth motor. The two other conduit runs (elevation sensor to elevation limit switch conduit run and the azimuth sensor to the azimuth limit switch conduit run) will be included with the interface box but not attached to anything - the installer will have to place these. The Teflon tape included with the installation kit can be used on any conduit fitting which cannot accept a sealing gasket or O ring (such as the 1/2" to 3/4" bushing used on the limit switches).

Once the conduit has been attached the wiring connections can be made.

The installer must make the following connections (please refer to figures E1, E2 and E3).

- 1. The RC2000 to Interface Box Interconnect cable must be installed. Make the connections at the RC2000. Refer to Chapter 3 in the RC2000 manual for more information on the connection at the RC2000.
- 2. The motor control signals on the RC2000 to Interface Box interconnect cable must be attached to the AZ1_CTL, AZ2_CTL, EL1_CTL, and EL2_CTL terminals on the circuit board in the interface box.
- 3. The sensor cables in the RC2000 to Interface Box interconnect cable will have to be spliced to the CBL-3_20-SHLD in the interface box. Please reread section 3 of this manual and refer to figure 7 in the RC2K90INT-1 interface box manual before making the splice. Use the appropriate terminal block points to make the splice. Proper connection of the sensors is critical to the operation of the antenna controller.
- 4. Connect the sensor cables to the sensors (refer to figure E1 and E2). At the sensors, cut off the drain wire and place a piece of heat shrink tubing over the sensor cable where the insulation is cut so that the shield does not come in contact with the sensor housing. Use the 3M Scotchlok connectors to make the connections.
- 5. At the azimuth and elevation motor terminal boxes, connect the 16/3 cables to the motor lead wires (refer to figure E1 and E2). Use the butt type crimp connectors to make the connections. The motor input leads are labeled A1 and A2. The green wire is the motor ground wire.
- 6. At the azimuth and elevation limit switches connect the 16/2 cables to the limit switches (refer to figure E3). The diodes and the jumper should be installed. Use the spaded terminals for these connections.



EASi 4.5m Antenna Installation Kit

Figure E1


67



Figure E3

When all this has been completed connect the interface box to AC power. Please refer to section 2 for information concerning the AC hookup.

5 RC2000 Software Configuration

The RC2000 stores certain parameters and configuration data in non-volatile memory. These parameters are viewed and modified via the controller's CONFIG mode and are referred to as CONFIG mode items. Some CONFIG mode items contain information which optimize the controller's auto move algorithms to the electromechanical drive system employed by the antenna. Other CONFIG mode items signal the controller as to what type of equipment the RC2000 is interfaced with. The values assigned to the following CONFIG mode items are appropriate for the EASi 4.5 meter. For more information on the purpose of these CONFIG mode items please consult the RC2000 antenna controller manual.

CONFIG Mode Item	Required Value for Operation with the EASi 4.5 m antenna	Comments	
AutoPol Enable	0 - DISABLE	AutoPol disabled.	
Simultaneous Az/El Enable	1 - ENABLE	The RC2K90INT-2E supports simultaneous azimuth and elevation movement.	
Az Slow Speed	254	A slow speed value of 254 disables the RC2000's pulse	
El Slow Speed		width modulation based slow speed system. Failure to properly configure this CONFIG mode item can result in damage to the interface box.	
Rotating Feed Present	1 - YES	When this CONFIG mode item is set to one, the controller assumes that a 3 wire servo type polarization control device is not present and the former polarotor output become the FAST/SLOW speed control. The RC2K90INT-2E system assumes the use of a 24VDC-type rotating feed with potentiometer position feedback. The RC2000 must have the RC2KPOL option installed.	
Az Drive Options Enable	1 - ENABLE	When this CONFIG mode item is enabled the user has access to the Az/El Fast Slow Threshold, 'Auto Retry	
El Drive Options Enable		Coast Thresholds, and Azim and Elev Max Position Error CONFIG Mode items.	
Az Auto Retry Attempts	2	The controller will make this number of attempts to get	
El Auto Retry Attempts		within 'Max Position Error counts of a target position.	
Az Fast Deadband	2000 milliseconds	The controller will allow this number of milli-Seconds	
El Fast Deadband		for the antenna to coast to a stop. If RUNAWAY errors occur the value of this parameter can be set to this number plus 1 to disable the accumulation of counts when the antenna is not commanded to move or is not coasting to a stop. This will disable the RUNAWAY error.	

CONFIG Mode Item	Required Value for Operation with the EASi 4.5 m antenna	Comments	
Az Slow Deadband	1000 milliseconds	The controller will allow this number of milli-Seconds for the antenna to coast to a stop. For Inclined-orbit tracking operations, the last two digits (nnMM) tell the controller to not schedule a peakup when Step Tracking within MM0 seconds of a time corresponding to a Program Track table entry. This prevents 'holes' from occurring in the program track table. See the troubleshooting section of the RC2000 manual for more information.	
Az Coast Threshold	2 position counts	When moving towards a target position in either	
El Coast Threshold	4 position counts	azimuth or elevation, the controller will turn off the motors when the position reaches a point; this is the number of counts away from the target position. The idea is that the antenna will coast into position.	
Az Max Position Error	2 position counts	This parameter is used when the controller is attempting to automatically move the antenna in azimuth or elevation to a target position. If (after a move) the resting position of the antenna is greater than 8 counts from the target position the controller will initiate another auto move to attempt to hit the target position if the number of retry attempts initiated so far is not greater than that specified by the Az/El Auto Move Retry Attempts CONFIG mode item.	
El Max Position Error	3 position counts		
Az Fast/Slow Threshold	80 position counts	These CONFIG mode items are used to set the number	
El Fast/Slow Threshold		of counts before a target position is reached that the controller switches the speed of the drive from fast to slow. There is a separate value for each axis.	
Antenna Size	450 cm	Appropriate for RC2000C only	
Az Constant	X counts per radian	This is the approximate number of position counts per radian of antenna azimuth movement.	
El Constant	X counts per radian	This is the approximate number of position counts per radian of antenna elevation movement.	
Max Track Error	X tenths of a dB	Appropriate for RC2000C only	
Search Enable	1-ENABLE	Appropriate for RC2000C only. For transmit applications the search feature should be disabled. Please see the description of TRACK mode in the RC2000 manual for more information.	

6 Bill Of Materials

Installation Kit

Ouan	Model/Description	Manufacturer	Comments (Ref Designators)
4'	LA11-50	Electri-Flex	1/2" Liquid Tight Steel Core Flexible Conduit
2	GY-4Q-50	Oz/Gedney	1/2" Straight Conduit Connector
5	GY-4Q-950	Oz/Gedney	1/2" 90 Degree Conduit Connector
1	GY-4Q-450	Oz/Gedney	1/2" 45 Degree Conduit Connector
2	KKR-21	Killark	3/4" to 1/2" Conduit Bushing
2	CN-6A-50 COUPL		1/2" Galvanized Rigid Coupling
2	CN-6A-50 XCLS		1/2" X - Close Galvanized Nipple
6	Butt Connector		Crimp Type, Insulated, 16-14 AWG for Motor Connections
16	Spade Terminal		Crimp Type, Insulated, 22-16 AWG for Limit
			Switch Connections
14	UR Connector	3M	Red Scotchlock with dielectric grease
16"	FIT-221-3/64	Alpha	3/64" heat shrink - Covers Drain Wire at
			Sensor Cable Splice
8"	FIT-221-1/4	Alpha	1/4" heat shrink - Covers the Break in the
			Insulation at the Sensor Cable (Belden 8772)
	TYT 221 2/2		Splice
6.,	FIT-221-3/8	Alpha	3/8" heat shrink - Covers the Break in the
			Splice
8	A" cable tie		Tie for Sensor Cable Splice
10	6" cable tie		Tie for General Use Inside Interface Box
10	8" cable tie		Tie Used to Join Azim/Elev Motor and
10	o cable tie		Sensor/Limit Conduits (Weather Proof and
			Ultraviolet Resistant)
12	9772	Dell City Wire	Adhesive Cable Tie Point
		Co.	
2	GI752	General	High Current Steering Diode for Limit
		Instrument	Switches
2	2 1/2" Jumpers, 16 AWG		For Use in Limit Switches
1	Tube of RTV Sealer		Used for Misc. Sealing
1	9850	KB Electronics,	0.006 ohm Plug-In Horsepower Resistor for
		Inc.	KBPB-125 Motor Drive Module. This
			appropriate for use with 1 $1/2$ HP 1750 RPM
			90 volt DC motors used.

Quan	Model/Description	Manufacturer	Comments (Ref Designators)
1	M-N4_20_20_8	Hammond	Nema 4 Enclosure 20X20X8 w/Plate
2	FB-KBPB-125A	KB Electronics	KBPB 115V
2	HT-KBPB-9861	KB Electronics	KBPB 1 1/2 HP Heatsink
1	2K90INT W/D_S	RCI	Dual speed relay circuit board
1	SW-PANIC-22_5	Switches Plus	Emergency stop switch w/Legend
47	CDT-M-0_5 LQT	Western Extralite	1/2 Liquid Tight Steel Core Flexible Conduit
5	CN-GY_5Q50	Oz/Gedney	1/2" Straight Conduit Connector
1	CN-GY-RB-3704	Western Extralite	1" .85-1.0 Cord Connector
1	LQT-3224	Sealcon	Liquid Tight 1/2" NPT Connector w/nut & seal
1	LQT-1_NPT	Sealcon	Liquid Tight 1" NPT Connector w/nut & seal
1	LQT-1_5 NPT	Sealcon	Liquid Tight 1 1/2" NPT Connector w/nut & seal
	W-10G-BLACK	Western Extralite	10 AWG for AC Entry
	W-10G-WHITE	Western Extralite	10 AWG for AC Entry
	W-10G-BLACK	Western Extralite	10 AWG for AC Entry
	W-16G-GREEN	Western Extralite	16 AWG for Motors and Limit Switches
	W-16G-BLACK	Western Extralite	16 AWG for Motors and Limit Switches
	W-16G-WHITE	Western Extralite	16 AWG for Motors and Limit Switches
23	CBL-3_20 SHLD	Belden	3 conductor shielded cable with drain 20 AWG (8772)
16	CN-TS6_12WP	Allied	16 Position Euro Strip
1	CN-RC90INTWH	American Cable	Wire Harness Custom Made
4	FH-354901-GY	Newark	Spare fuse holders-single position
2	F-12A-SB-C	Digi-Key	Spare fuses armature
2	F-25A-FB-C	Digi-Key	Spare fuses line
1	HTR-100W-115V	Barr-Thorpe	Electric heater fan-forced 100W
1	FH-354902-GY	Newark	Spare fuse holder-double position
2	F-2A-FB-G	Digi-Key	Heater fuse, w/spare
	Heatshrink	RCI	Various lengths and diameters
	Cable Ties/Holddowns	RCI	Various lengths and quantities
	Laminated Schematic	RCI	2K90INT CB and Wiring Diagram
	Hardware	RCI	Various threads and lengths
	Serial Number Labels	RCI	S/N and Motor Designator Labels
2	RY-PRD7AY0-120	Tyco Electronics	Power Relay

Antenna Interface Unit

7 Installation Checklist

Before the installation, the following items should be addressed....

- Fused AC power with a local disconnect must be present at the antenna pad. The installation should conform to the NEC (National Electric Code) or any other applicable codes. Please refer to section 2 -AC Power. The user is responsible for getting the AC power to the interface box - make provisions for any conduit or fittings which may be needed.
- 2. The installer must obtain and route the RC2000 to interface box interconnect cable. The RC2000 is designed for rack mounting indoors and can be powered by either 110 or 220/240 VAC. Please refer to section 3 for the specification of the interface cable. The user is responsible for any conduit or fittings required to route the interface cable to the interface box.
- 3. The RC2000C Az/El Inclined Orbit Satellite Tracking Antenna Controller requires an analog voltage input which is proportional to the satellite signal strength. The range of the AGC input voltage is 0 to 10 volts. The RC2000 can accept two channels of AGC signal strength information and has gain and offset pots for each channel. This allows the RC2000 to work with any analog voltage which swings over any part of the 0 to 10 volt input range. The controller can be configured via software to accept negative polarity AGC inputs (i.e. a strong received signal corresponds to a smaller analog voltage).

8 Tools and Materials Required For Installation

- Wiring Tools: wire cutters, wire stripper, crimp connector crimp tool.
- Heat gun or a lighter for use with heat shrink tubing.
- Hack saw for cutting liquid tight steel reinforced conduit.
- A fine straight bladed screwdriver for use with the AGC GAIN and OFFSET pots and the screw terminals on the circuit board in the interface box (tip 0.1" inch wide x .03" thick). A jewelers screw driver set may include these sizes.
- Phillips and straight bladed screwdrivers for gaining access to the interface box, the terminal boxes on the sensors, limit switches, and motors.
- A 12" Crescent wrench for working with the conduit fittings.
- Channel Lock pliers for working with conduit fittings. A regular set of pliers for use with the 3M Scotchlok connectors.

9 Attachments

Pulse Sensor Data Sheet (Dart CF-H1 or Powermation DTK-056M1

Limit Switch Data Sheet (Elevation Limit Switch - Gemco 2006-402L60C, Azimuth Limit Switch - 2006-402L30C)

A Note

Thank you for your support of our products. We appreciate your comments. If you find errors or omissions in this manual or any deficiencies in our products please contact us.

Research Concepts, Inc. • 9501 Dice Lane • Lenexa, Kansas 66215 • USA Phone: 913/422-0210 • Fax: 913/422-0211 • E-mail: <u>support@researchconcepts.com</u> Website: <u>www.researchconcepts.com</u>